

Backyard BullsEye™ 2-IN-1 Yard Game Manual

OWNER'S MANUAL

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT.


WARNING:

1. Adult assembly required.
2. Do not use the product in strong wind.
3. Do not aim at eyes or face.

ASSEMBLY

1. Find a solid, level grassy area that is clear of debris.
2. Remove the package contents (dartboard and self-stick balls).
3. Before inflating, open the valve on the anchor bag and fill with water.
4. Use an air pump to inflate the dartboard and balls (pump not included).

NOTE: Do not over-inflate the product as this may damage the product.



NOTE: All drawings for illustration purpose only. May not reflect actual product. Not to scale.

MAINTENANCE AND STORAGE

1. After use, use a damp cloth to gently clean all surfaces.
NOTE: Never use solvents or other chemicals that may damage the product.
2. Store in a dry place, with a temperature higher than 15°C/59°F, out of reach of children.

