










Dell Pro 27 Monitor
E2726DS/E2726HS
Schnellstartanleitung



























1




2




3





Dell Display- und Peripheriegeräte-Manager
Dell.com/support/ddpm



Dell.com/support/E2726DS
Dell.com/support/E2726HS