








Dell 24 Monitor




SE2426H

Snelstartgids












1


4



3



2











[Dell.com/support/SE2426H](https://Dell.com/support/SE2426H)