











Dell Pro P 34 USB-C Hub Webcam Monitor




P3426WEV


Quick Start Guide


































Dell Display and Peripheral Manager
Dell.com/support/ddpm



KVM



Dell.com/support/P3426WEV

