










## Dell Pro P 27 USB-C Hub Conferencing Monitor




P2726DEB


### Quick Start Guide



























1







2




3












Dell Display and Peripheral Manager  
[Dell.com/support/ddpm](https://Dell.com/support/ddpm)



KVM



Daisy Chain



[Dell.com/support/P2726DEB](https://Dell.com/support/P2726DEB)