










Dell Pro P 27 USB-C Hub Webcam-Monitor
P2726DEV
Schnellstartanleitung









2




3






4





1

















1






2




3












Dell Display and Peripheral Manager
Dell.com/support/ddpm



KVM



Reihenschaltung



Dell.com/support/P2726DEV