










Dell Pro P 24 USB-C Hub Conferencing Monitor




P2426HEB


Quick Start Guide


























1







2




3












Dell Display and Peripheral Manager
Dell.com/support/ddpm



KVM



Daisy Chain



Dell.com/support/P2426HEB