












Moniteur Dell UltraSharp 32 4K QD-OLED
U3226Q


Guide de démarrage rapide









2



3





4





1


















1











2




3












Dell Display and Peripheral Manager
Dell.com/support/ddpm



KVM



Connexion en cascade



Dell.com/support/U3226Q