







Dell UltraSharp 32 4K QD-OLED-beeldscherm

U3226Q


Snelstartgids






D

D




HDMI

HDMI




Thunderbolt 4




Thunderbolt 4







USB-C


USB Type-A





















1











2




3












Dell Display and Peripheral Manager
Dell.com/support/ddpm



KVM



Daisy chain



Dell.com/support/U3226Q