



Dell Pro P 22 Monitor

P2226H

Dell Pro P 24 Monitor

P2426H

Dell Pro P 24 16:10 Monitor






P2426

Dell Pro P 27 Monitor


P2726H




Quick Start Guide











* For selected countries only




















1




2




3





Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dell.com/support/P2226H

Dell.com/support/P2426H

Dell.com/support/P2426

Dell.com/support/P2726H