

RM-DE-T3

VENDOR
DELL

SUPPORTED MODELS
EDGE 710-5G
EDGE 710-W

COLOR
BLACK

DIMENSIONS
(HxWxD)
44 x 483 x 217 mm
1.73 x 19.00 x 8.54 inch



MOUNTING INSTRUCTIONS

Removing punch outs for antennas (only with 1 appliance)

1. Use a hammer to punch out the pre-scored holes. Position the hammer close to the pre-scored edge.

Removing cutout for a second appliance

1. Remove the front plate by applying force to the top part of the cutout. When the top part is loose, move it in both directions until it breaks from the rack.

Mounting appliance

1. Place the appliance on the rack and secure with two bolts.
2. Place the power supply on the extension plate and secure it with two zip ties. Secure the excess length to the rack with the third zip tie.
3. Hook the extension plate into the rack.
4. Connect the appliance to the coupler with the supplied cable.

Please ensure proper ventilation according to the network appliance

PACKAGE CONTENTS

- 1 Rackmount
- 1 Extension plate
- 8 Bolts
- 6 Zip ties

Appliance not included.



**CONSIDER THE ENVIRONMENT,
RECYCLE WHERE APPLICABLE**

QUESTIONS

Email support@rackmount.it or contact your reseller.

RACKMOUNT.IT

Install Guide - 20-02-2026