




Philips
Mini Speaker

Party extender

Use with Philips party machine
Dynamic light
240W



FWP1000



Extend your party machine music

An extra speaker for wider reach

Party on with the Philips Mini speaker. The 240W speaker adds life to parties, bringing music to any part of your home. It works with all Philips party machines, and is designed for flexible placement and easy set up.

Extend your party machine music

- 240W RMS total output power
- Flexible placement around the house
- Simple setup with any Philips party machines
- Dynamic lighting for dancing to the beat

PHILIPS

Mini Speaker

Party extender Use with Philips party machine, Dynamic light, 240W

Specifications

Sound

- Total Sound Power (RMS): 240 W

Loudspeakers

- Speaker drivers: 2" tweeter, 5.25" woofer
- Loudspeaker enhancement: 2-way
- Speaker types: bass reflex speaker system

Accessories

- User Manual: Spanish, B-Portuguese
- Cables/Connection: *Flat pin adaptor, power cord

- Others: Quick start guide
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 15 kg
- Packaging height: 400 mm
- Packaging width: 780 mm
- Packaging depth: 430 mm
- Product dimensions (WxDxH): 704x364x324 mm

Power

- Power supply: 100 - 240V AC, 50/60Hz

FWP1000/05

Highlights

Dynamic lighting



Step in time to the dazzling beat of music. Cool lights blink to the rhythm of songs, adding fun and excitement to tunes. When you don't want the lights on, you can simply turn the feature off. Add glam and spice to dance parties, sizzling celebrations and cool events with these sensational dynamic lights.



Issue date 2015-01-25

Version: 1.0.6

12 NC: 8670 000 85928
EAN: 08 71258 16297 55

© 2015 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Avoid extensive use of the set in a volume higher than 85 decibel
because this may damage your hearing.