


Contour

CONTOUR TOUCH & BALANCE FULL-SIZE KEYBOARD COMBO WIRED

Product manual



Contour

CONTOUR TOUCH WIRED

Product manual




TABLE OF CONTENTS.

What's in the box	1
Meet Contour Touch	1
Get set up for comfort	2
Quick connect guide	2
Touchpad & buttons customization	3
SnapLinks	5
Cleaning & maintenance	6




WHAT'S IN THE BOX.

You'll find everything you need for a seamless setup inside the box.



MEET CONTOUR TOUCH.




GET SET UP FOR COMFORT.

Before you start working, set yourself up for all-day comfort.

Relax your shoulders. Keep your elbows at 90 degrees, close to your body. Your forearms should be parallel to the floor, with wrists in a straight, neutral position.

Line up the H key of your keyboard and the center of the touchpad with your monitor – and your body. This helps keep your posture natural and balanced.


Position the keyboard close to the touchpad, and keep the Contour Touch far enough from the desk edge to support your forearms and reduce wrist twisting.



QUICK CONNECT GUIDE.

If you have the wired version of Contour Touch, just plug the USB cable into any available USB port in your PC.

Your computer will connect to the touchpad automatically. No extra steps needed.




The cable comes with a USB-A adapter pre-installed.

Just slide the adapter off and plug in the USB-C connector instead

TOUCHPAD & BUTTONS CUSTOMIZATION.

Touchpad gestures




Contour Touch comes with pre-set touchpad gestures to help you boost your productivity.

1. **Zoom:** Move two fingers apart to zoom in or pinch them together to zoom out
2. **Scroll:** Slide two fingers up or down or from side to side to scroll through pages or lists
3. **Right click:** Tap once with two fingers anywhere or click in the lower-right corner
4. **Double click:** Tap twice with one finger to open or select an item
5. **Open search:** Tap once with three fingers to open search
6. **Drag and drop:** Tap twice and hold with one finger, then slide to move an item; release to drop it or deep press and hold with one finger, then use another finger to drag the item around
7. **Switch apps:** Swipe three fingers left or right to switch between open applications
8. **Switch desktops:** Swipe four fingers left or right to move between multiple desktops
9. **Task view:** Swipe three fingers up to see all open windows and switch between them
10. **Show desktop:** Swipe three fingers down to reveal the desktop


Want to change the behaviour of the touchpad?

Open your Windows Settings to change cursor speed, gestures, disable right click and much more.

Go to Settings – Bluetooth & devices – Touchpad



Shortcut buttons



Want to make it your own?


Download Contour software to customize and unlock the full potential of your Contour Touch

Visit cd.now/sw to get started

SNAPLINKS.

Using Contour Touch with Balance Full-Size Keyboard?

Use the SnapLinks (included in your Contour Touch box) to seamlessly attach the two devices. This creates perfect alignment – improving comfort and giving you a stable setup, while you work.



Step 1: Turn your Contour Touch around and attach the two SnapLinks to the SnapLink attachment points



Step 2: Turn the Contour Touch back around and place it on your desk with the touchpad facing up. Press the Balance Full-Size Keyboard onto the SnapLinks until it clicks into place

CLEANING & MAINTENANCE.

Contour Touch is designed to be easy to maintain – and yes, it can be safely disinfected.

Follow these steps to clean the product safely and keep your warranty intact:

- Unplug any cables and make sure the device is turned off before cleaning
- Use an alcohol-based solution (up to 70% concentration) for disinfection
- Never apply liquid directly to the device. Instead, lightly dampen a soft, clean cloth with the solution and gently wipe down the surface
- Avoid soaking, dripping, or letting moisture pool. Too much liquid can harm sensitive components
- Once wiped, make sure everything is dry before using the device again

Contour

BALANCE FULL-SIZE KEYBOARD WIRED

Product manual





TABLE OF CONTENTS.

What's in the box	7
Meet Balance	7
Quick connect guide	8
Tilt options	9
Media keys & customization	10
Function keys	11
Caps lock & num lock	12
Cleaning & maintenance	13
Safety, legal & warranty info	13




WHAT'S IN THE BOX.

You'll find everything you need for a seamless set-up inside the box.




MEET BALANCE.



QUICK CONNECT GUIDE.

If you have the wired version of Balance Keyboard, just plug the USB cable into any available USB port in your PC.

Your computer will connect to the keyboard automatically. No extra steps needed.




The cable comes with a USB-A adaptor pre-installed


Just slide the adaptor off and plug in the USB-C connector instead

TILT OPTIONS.

Balance Keyboard gives you five tilt options to suit your set-up, posture needs, and personal preference.



1. **Flat** – for Touch, Balance Wrist Rest and UniMouse (recommended ergonomic option)
2. **Positive tilt** – for Touch, Balance Wrist Rest and UniMouse
3. **Elevated positive tilt** – for RollerMouse or SliderMouse
4. **Elevated** – for RollerMouse or SliderMouse
5. **Negative tilt** – for RollerMouse or SliderMouse (recommended ergonomic option)



The + and – symbols on the tilt legs show you if you are choosing positive or negative tilt

MEDIA KEYS & CUSTOMISATION.

Your Balance Keyboard comes ready with preset media keys to get you going right away.

Want to make it your own?

Download the Contour software to customise the media keys based on your preferences and unlock the full potential of your keyboard

[Visit cd.now/sw](https://cd.now/sw) to get started

Full-Size media keys




Number	Default assignment
1	Mute/unmute sound
2	Volume down
3	Volume up
4	Mute/unmute microphone
5	Previous track
6	Play/pause
7	Next track
8	Brightness down
9	Brightness up
10	Task view
11	Show desktop
12	Search
13	Open settings
14	Open calculator
15	Clear entry
16	Negative number toggle
17	Lock computer
18	Open Copilot or other AI assistant



FUNCTION KEYS.

Function keys & fn lock

By default, the top row of your keyboard is set for media keys like volume, play/pause, and more. Need traditional F-keys instead? You've got options:



For one-time use:

Hold down the fn key and short press any F-key



To switch modes:

Want to make F-keys the default? Just hold down the fn key and short press the esc key

The fn lock LED will turn on

To switch back to media keys as default, hold down the fn key and short press the esc key again

CAPS LOCK & NUM LOCK.



Caps lock:

Press the key once to turn caps lock on or off, when LED on the key is lit, caps Lock is on



Num lock:

Press the key once to switch your numpad from numbers to navigation – or back again

CLEANING & MAINTENANCE.

Balance Keyboard is designed to be easy to maintain – and yes, it can be safely disinfected.

Follow these steps to clean the product safely and keep your warranty intact:

- Unplug any cables and make sure the device is turned off before cleaning
- Use an alcohol-based solution (up to 70% concentration) for disinfection
- Never apply liquid directly to the keyboard. Instead, lightly dampen a soft, clean cloth with the solution and gently wipe down the surface
- Avoid soaking, dripping, or letting moisture pool. Too much liquid can harm sensitive components
- Once wiped, make sure everything is dry before using the keyboard again

SAFETY, LEGAL AND WARRANTY INFO.

Warranty

If there is a functional defect due to faulty manufacturing, we will replace the product. This warranty does not cover damage that results from misuse of the product.

Attention!

If you attempt to dismantle your product, you will invalidate your warranty.

Contour Design Nordic A/S

Nyropsgade 43, 1. floor
DK-1602 Copenhagen V, Denmark
Contact Support: cd.now/support

Contour Innovations LLC

10 Industrial Drive
Windham, New Hampshire 03087, USA
Contact Support: cd.now/support

For more information please visit:
www.contourdesign.com

Tested to comply with FCC and
IC standards.

