





EN Quick start guide
ES Guía de configuración rápida
RU Краткое руководство

PHILIPS


1




2




4



3



5




All registered and unregistered trademarks are property of their respective owners.
© 2012 Koninklijke Philips Electronics N.V.
All rights reserved.


CMD310_05_QSG_V2.0



6



7



EN

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome. Read and understand all instructions before you use this product. If damage is caused by failure to follow the instructions, the warranty does not apply.

1 What's in the box (Fig. 1)

1. Main unit and front panel (with a sleeve)	2. Trim plate
3. ISO standard connector	4. Rubber cushion
5. Screw x 1	6. Disassembly tool x 2
7. User manual	8. Quick start guide

2 Connect wires (Fig. 2)

- Check the car's wiring carefully, and then connect them to the supplied ISO wires. (Fig. 2 - 1)

Connector	Connect to
1 Yellow wire	The +12V car battery which is live at all times
2 Blue/White wire	The electric antenna control lead or power supply lead of the antenna booster. If there is no electric antenna or antenna booster, or it is manually operated telescopic antenna, it is unnecessary to connect this lead.
3 Black wire	A metal surface of the car. Connect the black ground (earth) lead before connecting the yellow and red power supply leads.
4 Red wire	The +12V power terminal which is live in the accessory (ACO) position of the ignition switch. If there is no accessory position, connect to the +12V car battery terminal that is always live. Make sure that the black ground (earth) lead is connected to a metal surface of the car first.
5 Green and green/black wires	Left speaker (rear)
6 White and white/black wires	Left speaker (front)
7 Gray and gray/black wires	Right speaker (front)
8 Purple and purple/black wires	Right speaker (rear)

- Connect the other end of the supplied standard connector to the car audio system. (Fig. 2 - 2)

Connector	Connect to
1 ANTENNA	Antenna for radio
2 External Mic	An external microphone for phone call
3 SUBWOOFER (Socket)	Subwoofer
4 REAR LINE OUT L (Socket)	Rear left speaker
5 REAR LINE OUT R (Socket)	Rear right speaker
6 OE REMOTE (Brown)	OE remote
7 FRONT LINE OUT L	Front left speaker
8 FRONT LINE OUT R	Front right speaker

3 Mount into the dashboard (Fig. 3)

If the car does not have an on-board drive or navigation computer, disconnect the negative terminal of the car battery.

- If you disconnect the car battery in a car that has an on-board drive or navigation computer, the computer may lose its memory.
- If the car battery is not disconnected, to avoid short-circuit, make sure that the bare wires do not touch each other.

- Make sure that the car dashboard opening is within the indicated measurements. (Fig. 3 - 1)
- Install the sleeve into the dashboard and bend the tabs outwards to fix the sleeve. (Fig. 3 - 2)

Note

- If the system is not fixed by sleeve but by the supplied screws, skip this step.

- Place the supplied rubber cushion over the end of the mounting bolt. (Fig. 3 - 3)
- Slide the system into the dashboard until you hear a "click". (Fig. 3 - 4)
- Attach the trim plate. (Fig. 3 - 5)
- Reconnect the negative terminal of the car battery.

4 Turn on

- Press .
- [WELCOME] scrolls.
 - To turn off the system, press and hold until [GOODBYE] is displayed.

5 Set the clock

- Press and hold to access the system menu.
- Press repeatedly until [CLOCK] and the current time are displayed.
 - If the clock is not set before, [00:00] is displayed.
- Rotate to set the hour.
- Press to confirm.
- Rotate to set the minute.
- Press to confirm.

6 Select a source

Note

- When all other sources are unavailable, the system switches the source to [RADIO] automatically.

- Press **SOURCE** repeatedly to select a source.
- [RADIO]: FM/AM radio
 - [MP3-LINK]: the audio input through the MP3-LINK socket
 - [BT AUDIO]: the audio transferred from a Bluetooth device
 - [USB]: When a USB storage device is connected and recognized, you can select this source to play audio files that are stored on it.
 - [iPHONE]: When an iPhone or iPod touch is connected and recognized, you can select this source to play the playlist of iPhone or iPod touch.

7 Listen to radio

Select a radio region

You can select a radio region that matches your location.

- Press and hold to access the system menu.
- Press repeatedly until [AREA] is displayed.
- Rotate to select an option.
 - [USA] (United States)
 - [EUR] (Western Europe)
 - [RUS] (Russia)
 - [AUS] (Australia)
 - [EAS] (Middle East)
 - [ASI] (Asia Pacific)
 - [JAP] (Japan)
 - [LAT] (Latin America)

