

Head

Gently exfoliates the skin

For weekly use Replace every 6 months Easy to replace



SC5992/10

Exfoliation brush head for all skin types

For clean and soft skin

The Exfoliation brush head gently removes dull and dead skin cells. Unique combination of shorter and longer bristles provides deeper cleaning.

Developed to gently yet effectively exfoliate skin

• Exfoliation brush for all skin types

Deep gentle cleansing

• Increases the absorption of your favourite skincare products

Easy to replace

- · Click-on brush head; easy to put on and take off
- Replace every 6 months

5-in-1 bristle technology

• Unique composition of face cleansing brush bristles





Specifications

Compatibility

· Use with all VisaPure models

Benefits

• Type of skin: For all skin types

Ease of use

· Easy to clean

- · Waterproof: Can be used in the shower
- Use with cleansing product
- · Replacement: Easy click-on brush head
- Recommended replacement: Every 6 months

Service

• Warranty: 2-year limited warranty

Highlights

Exfoliation brush

Specially designed bristle shape: the shorter bristles gently exfoliate while the longer ones wipe away the dead skin cells.

Increases absorption of creams

Cleansing with VisaPure means that you remove more make-up residue and dull and dead skin cells. Thanks to the deep cleansing effect, your favourite skincare products such as creams, serums and essences are better absorbed by the skin.

Face cleansing brush bristles
All VisaPure brushes have unique 5-in-1 bristle technology. Each bristle is polished twice and silkysoft ends ensure a smooth glide. VisaPure bristles are extra long for absolute skin comfort. To ensure efficacy, VisaPure bristles are up to 3 x smaller than your pores and the dense brush reaches more pores in one treatment to give a soft, luxurious feel whilst cleansing. The bristle material is specially selected to be water resistant.

Click-on brush head

Simply click the brush head on and off. Easy to fit, our brush heads are compatible across all Visapure

Replace every 6 months

For best results, replace the brush every 6 months. The brush is easy to replace by simply pulling it off the device.



Issue date 2018-02-22

© 2018 Koninklijke Philips N.V. All Rights reserved.

Version: 7.0.1

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

EAN: 08 71010 35899 07

www.philips.com