



Allows milk to flow into the bottle

Find matching products on the specifications tab

The valve allows milk to be transferred from the pump into the bottle.

Ease of using Philips spare parts

• Easily renew your product with original Philips parts

Valve ScF160/06

Specifications

Country of origin England **Development stages**Stage: 0–6 months

© 2024 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2024-10-28

