



Philips
Normal Skin Cleansing
Brush

Replace every 3 months

For daily use
For normal to oily skin
Easy to replace



SC5990/00

Replacement Brush Head for Normal Skin

For clean and soft skin

Replacement Brush Head for Normal Skin care. For use only with Philips VisaPure Essential facial cleansing brush.

Developed for normal to oily skin types

- 17000 soft bristles for deep skin cleansing

Easy to maneuver to focus on hard-to-reach areas

- Perfect size and shape to easily reach all face areas

Easy to replace

- Click-on brush head; easy to put on and take off
- For optimal results, replace the brush every three months



asimpleswitch.com

PHILIPS

Normal Skin Cleansing Brush

Replace every 3 months For daily use, For normal to oily skin, Easy to replace

Specifications

Benefits

- Type of skin: For all skin types

Ease of use

- Compatible with: Philips VisaPure Essential

- Replacement: Easy snap-on brush head
- Recommended replacement: Every 3 months

Service

- Warranty: 2-year limited warranty

SC5990/00

Highlights

Size and shape

Perfect size and shape to easily reach all face areas

Brush Bristles

17000 soft filaments gently massage and deeply cleanse the skin like 17000 fingers.

Click-on brush head

Simply click on or click off the brush head. Easy to fit, our brush heads are compatible across all Visapure models.

Long operating time

For optimal results, replace the brush every three months



Issue date 2017-12-21

Version: 6.0.1

EAN: 08 71010 35898 60

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com