



Paddle for thorough kneading and even mixing

Check compatibility data

If the paddle of your bread maker is worn or damaged, replace it with this original spare part from Philips and enjoy your freshly baked bread in the morning again.

Ease of using Philips spare parts

• Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product type:: HD9020/40

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-02-07 Version: 1.0.3

EAN: 08 71010 36103 04

www.philips.com

