



Philips
Water container

Original

Silent blue

CRP697

For water storage in your SENSEO® coffee machine

Go to the Specifications Tab to check your matching product

A water container should be cleaned regularly. Whenever cleaning is required, you'll be pleased not to miss your coffee moment and to have an extra reservoir for your SENSEO® coffee machine. The tank contains 1.2 litres, for eight cups of coffee.

Ease of using Philips spare parts

- Renew your product with original Philips parts

PHILIPS
sense and simplicity

Water container
Original Silent blue

Specifications

Replaceable part

- Fits product types: HD7811/72

CRP697/01

Highlights

Easy replacement

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality and 1:1 exchange.



Issue date 2013-01-10

Version: 2.0.1

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com