



## To power the charger.

Find matching products on the specifications tab

The mains cord is designed to connect the HomeRun charger to your wall socket. When you need to replace your HomeRun's mains cord, this is the replacement that will fit your HomeRun's charger properly.

Mains cord CRP766/01

## Specifications

Replaceable part

Fits product type:: FC9910/01/A,

FC9910/01/B

Suitable for

HomeRun: FC9910/01/A, FC9910/01/B

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-02-05 Version: 1.0.1

