

Philips  
Cleaning tool

CRP769



To clean the roller brush and dust container.

Find matching products on the specifications tab

The cleaning tool helps to clean the HomeRun. The brush side can be used to remove fluff and dirt from the internals of the appliance, the toothed part can be used to remove entangled hairs from the roller brush.

**PHILIPS**

# Specifications

## Replaceable part

- Fits product type:: FC9910/01/A, FC9910/01/B

## Suitable for

- HomeRun: FC9910/01/A, FC9910/01/B



Issue date 2023-01-19

Version: 6.6.1

EAN: 08 71010 35977 80

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)