

PHILIPS

Cleaning tool

CRP769



To clean the rollerbrush and dustcontainer.

Find matching products on the specifications tab

The cleaning tool helps to clean the HomeRun. The brush side can be used to remove fluff and dirt from the internals of the appliance, the teathed part can be used to remove entangled hairs from the rollerbrush.

Specifications

Replaceable part

Fits product type :: FC9910/01/A,
FC9910/01/B

Suitable for

HomeRun: FC9910/01/A, FC9910/01/B

