

Keeps the cord out of the way

For comfortable and fast ironing

The Philips CordGuide keeps the cord securely fit to your ironing board so you can iron comfortably and fast. Forget about tripping on the cord, the CordGuide fits any standard ironing board to keep your cord in place.

Keeps the cord out of the way

- Fixes the cord to prevent creasing already ironed parts
- $\boldsymbol{\cdot}$ Prevents tangling of the cord while ironing
- · Prevents ironing or tripping over the cord

Easy to use

- · Easily fits all standard ironing boards
- Designed for steam iron appliances

Cord holder GC013/00

Highlights

No accidental creasing



CordGuide fixes the cord in one place on the ironing board, so that it will not accidentally drag and crease already ironed parts of the garment.

No tangling



The cord will not tangle while you are ironing.

No tripping over the cord

It prevents you from tripping over the cord, protecting it from being damaged and so you don't accidentally iron over it.

Fits on all ironing boards



CordGuide is easy to use. Just clip it on your ironing board and slot the cord of your iron inside. CordGuide fits on all standard ironing boards.

Designed for steam irons

The CordGuide is compatible with standard steam iron appliances.

Specifications

Size and weight

Packaging dimensions (WxHxL): $35 \times 28 \times 24 \text{ cm}$

Product dimensions (WxHxL): $10 \times 5 \times 4,4 \text{ cm}$ Total weight with packaging: 0.065 kg

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-03-05 Version: 9.2.1

EAN: 08 71010 36582 76

www.philips.com

