Epson **AcuLaser C4100T**

High-performance colour laser printer with 500-sheet paper cassette for business use

The Epson AcuLaser C4000 and Epson AcuLaser C4100provide businesses with high performance colour and monochrome printing solutions. They add crucial colour to your business, while producing high quality monochrome output at lower costs than many monochrome-only printers - and they are just as easy to operate. So now there´s no reason to buy two printers because perfect monochrome and colour solutions are available in one.

KEY FEATURES

- Single printer solutions for both colour and monochrome business printing
- Superb print quality at high speeds of 16 or 24 ppm
- Flexible, reliable and cost effective
- Easy to integrate and maintain
- Choice of printer configurations to cater for your requirements

EPSON®

EXCEED YOUR VISION

PRODUCT SPECIFICATIONS

PRINT

Max Duty cycle	100,000 pages per month

CONNECTIVITY

Interfaces	Ethernet interface (100 Base-TX / 10 Base-T), Parallel, USB 2.0 Type B

PAPER / MEDIA HANDLING

Paper Formats	A4

GENERAL

Product dimensions	439 x 638 x 445 mm (Width x Depth x Height)
Product weight	34 kg
Compatible Operating Systems	Mac OS 10.3+, Windows 2000, Windows XP

TECHNOLOGY

Application	Office Departmental

LOGISTICS INFORMATION

SKU	C11C538001BV
EAN code	8715946205724
Multiple Order Quantity	1 Units
Pallet Size Euro	2 Units

Epson **AcuLaser C4100T**

SUPPLIES

- AL-C4100 Fuser Unit 30k
  C13S053012 (100,000 pages)
- AL-C4100 Photoconductor Unit 30k
  C13S051093 (30,000 pages)
- Toner Cartridge Cyan 8k
  C13S050146 (8,000 pages)
- Toner Cartridge Yellow 8k
  C13S050148 (8,000 pages)
- Toner Cartridge Magenta 8k
  C13S050147 (8,000 pages)
- Toner Cartridge Black 10k
  C13S050149 (10,000 pages)
- AL-C4000/C4100 Transfer Unit 25k
  C13S053006 (25,000 pages)
- Color Laser Paper A4 - 10 x 250Sh (C13S041163)

OPTIONAL ACCESSORIES

- 20 GB HDD for EPL-N3000
  C12C824061

TONER CARTRIDGE COLLECTION PROGRAM

This free service helps us to collect and recycle used Epson toner cartridges in a safe and environmentally-friendly way. There are three easy ways to dispose of your empty cartridges and take an action role in reducing waste:

- Put them in a toner cartridge collection box which will be picked up once full
- Return them free of charge by Post
- Drop them off at an Epson Express Center. Please visit www.epson.com/recycle for more details about the program.

EPSON®