

Quick Start Guide







Step A **Connect**

Step B **Setup**

Step C **Enjoy**

What's in the Box?

You should find these items upon opening the box.




PHILIPS

Step A *Connect*

Connection

- 1 Connect the speaker wires to the **SPEAKERS** terminals.
- 2 Connect the power cord of the system to the AC power outlet.



Tip:

It is unnecessary to connect the DAB/ FM antenna since it is fixed to the main unit.


Notes for the remote control:

- First, select the source you wish to control by pressing one of the source select keys on the remote control (DISC or AUX, for example).
- Then select the desired function (▶||, ◀◀, ▶▶ for example).

Step B *Setup*

Setting the clock


- 1** In standby mode, press and hold **DISPLAY/CLOCK** on the remote control set for 2 seconds.
- 2** Press **PROG** on the remote control to select 12-hour or 24-hour display.
- 3** Press **DISPLAY/CLOCK** to confirm.
→ The clock digits for the hours flash.
- 4** Press **◀◀ / ▶▶** to set the hours.
- 5** Press **DISPLAY/CLOCK** again.
→ The clock digits for the minutes flash.
- 6** Press **◀◀ / ▶▶** to set the minutes.
- 7** Press **DISPLAY/CLOCK** to confirm the time.



Step C *Enjoy*

Playing a disc


- 1** Select **CD** source.
- 2** Lift the CD door on the top of the system to open the CD compartment.
- 3** Insert a disc with the printed side facing up and press down on **PULL TO OPEN** to close the CD door.
- 4** Press **▶▶** to start playback.
- 5** Press **■** to stop playback.



Step C *Enjoy*


Tuning to DAB stations

- 1 Press **SOURCE** (or **DAB** on the remote control) to select DAB to start an automatic search of available DAB stations.
- 2 Press **◀◀/▶▶** to change the DAB stations.
- 3 Press **▶▶** to confirm a selection.
- 4 To perform a local scan (in UK), press briefly **SCAN**.
To perform a full scan (outside UK), press and hold **SCAN**.
- 5 To access setup options, press **MENU**, then use the navigation control buttons to select.



Programming and tuning to FM stations

- 1 Select FMTUNER source.
- 2 Press **SCAN** for more than two seconds to program all available stations (FM only).
- 3 Press **PRESET +/-** (or **▲/▼** on the remote control) until the desired preset station is displayed.



Tip:

Detailed playback features and additional functions are described in the accompanied owner's manual.



© Royal Philips Electronics N.V. 2010
All rights reserved.

<http://www.philips.com>

MCB146_05_QSG_V3.0

