

Case Logic Luminosity™ Collection

Prosumer DSLR Zoom Holster

DSH-103

Protect your Pro DSLR or DSLR camera with battery grip, zoom lens and tripod mount attached in the easily accessible, top loading compartment. Want to shoot with a larger lens instead? Simply unzip bottom zipper and case expands to store camera with up to a 70-200mm lens. Multiple pockets store accessories and personal items and detachable, non-slip strap allows you to securely carry case across body or by the top grab handle.

Product Features:

1. Fits a Prosumer DSLR or DSLR with extra battery grip, zoom lens and tripod mount attached
2. Expandable zipper opens to provide extra depth (3"/18 cm) for a 70-200mm lens
3. Soft blue Nylex lining protects hardware surfaces and contrasts with camera gear to easily locate accessories
4. Adjustable snake divider offers extra layer of protection - simply wrap around camera and attach to wall for a snug fit to minimize movement within case
5. Zippered lid pocket conveniently stores slim camera accessory such as a lens cloth
6. Weather hood fits snugly over the bag to protect from the elements (when not in use, stuff in compartment on side of bag)

Colors:



BLACK



Retail: .