

PHILIPS


Sensitive Skin Cleansing Brush

Replace every 3 months


For daily use

Normal to sensitive skin

Easy to replace



SC5991/30



Sensitive Skin Replacement Brush Head

Ultra soft bristles for a more effective, gentle cleansing

Replacement Brush Head specifically designed for Sensitive Skin care. For use only with Philips PureRadiance facial cleansing brush.

Easy to maneuver to focus on hard-to-reach areas

- Perfect size and shape to easily reach all face areas

Easy to replace

- For optimal results, replace the brush every three months
- Easy to fit and compatible only with Philips PureRadiance

Developed for sensitive skin types

- Ultra soft bristles for a more effective, gentle cleaning
- Perfectly designed for optimal hygiene

Highlights

Size and shape

Perfect size and shape to easily reach all face areas

Long operating time

For optimal results, replace the brush every three months

Brush Bristles

The specially designed filaments are even thinner and softer than those of the normal brush head to deliver an even softer and delicate cleansing experience specific for sensitive skin.

Snap-on brush head

Easy to fit and compatible only with Philips PureRadiance.

Designed for optimal hygiene

The silky soft bristle material of all our VisaPure brush heads is a specially chosen, delicate nylon. This helps to ensure the brush heads are super easy to clean and keep fresh.

Specifications

Benefits

Type of skin: For sensitive skin

Ease of use

Compatible with: Philips PureRadiance

Replacement: Easy snap-on brush head

Recommended replacement: Every 3 months

