





Replacement Tip Sensitive

For use only with Philips VisaCare microdermabrasion: used in the comfort of your home, the combined exfoliation and vacuum massage gently stimulate your skin's natural renewal processes and address the first signs of aging.

Microdermabrasion tip Sensitive

- Microdermabrasion tip for mild treatment
- · Replace every 6 months

Easy to replace exfoliating tip

• Easy click-on tip



Highlights

Microdermabrasion Sensitive

Recommended to use for women new to microdermabrasion treatments, or for women with sensitive skin or in periods when the skin is more sensitive due to seasonal or hormonal changes. Developed with dermatologists, safe for home use. When using a new tip, always start again with a limited number of passes; allowing your skin to get used to iets more intense treatment.*

Easy fit

Easy to fit and compatible with Philips SC6220 and SC6240.

Replace every 6 months

For optimal results, it is recommended to replace the microdermabrasion tip every six months.

Specifications

Benefits

Type of skin: For sensitive skin

Ease of use

Cleaning: Wash under fresh water, with soap and brush

Compatible with: Philips SC6220, Philips SC6240

Recommended replacement: Every 6 months Replacement: Easy click-on tip



Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas — Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-07-30 Version: 8.2.1

EAN: 08 71010 36752 28

www.philips.com



* compared to a tip used twice a week for six months.