





Maintain your style

Replacement foil

Change shaving foil every 12 months for best results

Performance

• Dual shaver with trimmer shaves even the toughest beards

Easy to use

 ${\boldsymbol{\cdot}}\,$ 100% waterproof for use in the shower and easy cleaning

Replace and renew

· Change foil every 12 months for best results

Highlights

Dual foil shaver with trimmer



The dual foil shaver makes it easy to clean up stubble around your beard, even on your neck. The mid trimmer catches longer, tougher hairs and the 2 floating foils shave everything else perfectly smooth.

100% waterproof



Trim and shave where you want to, wet or dry. And when you're done, just rinse it off under the tap.

Change foil every 12 months



1. detach the shaver end of your Styleshaver. 2. Remove the old foil and cutters. 3. Place the new foil in the holder. 4. Place the new cutters into your Styleshaver and then click on the new holder and foil.

Specifications

Shaving foil

Fits product types: QS6140, QS6160, QS6141,

QS6161

Shaving foil per packaging: 1

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-12-05 Version: 3.0.1

EAN: 08 71010 36603 78

www.philips.com

