



33051/\*\*/16

Gebruiksaanwijzing

Notice d'emploi

Benutzerhandbuch


User manual

Manual de usuario





# PHILIPS



Incl.






Excl.




Type 1 → P4




Type 2 → P8




Type 1








①





②














Type 2









①













Philips Lighting Contact Centre  
Int. Business Reply Service  
I.B.R.S. / C.C.R.I. Numéro 10461  
5600 VB Eindhoven  
Pays-Bas / The Netherlands

[www.philips.com/homelighting](http://www.philips.com/homelighting)  
☎ +800 7445 4775

4404.016.96241  
Last update: 20/03/14