

33622/**/16




Gebruiksaanwijzing

Notice d'emploi

Benutzerhandbuch


User manual

Manual de usuario





PHILIPS



Incl.






Excl.




Type 1 ➔ P4




Type 2 ➔ P8





Type 1









①





②















Type 2










②



⑦









Philips Lighting Contact Centre
Int. Business Reply Service
I.B.R.S. / C.C.R.I. Numéro 10461
5600 VB Eindhoven
Pays-Bas / The Netherlands

www.philips.com/homelighting
 +800 7445 4775

4404.016.96031
Last update: 07/01/14