

# SONY



Mount the URX-P03 wireless receiver using the SMAD-P3 MI shoe adapter

**ni** Multi Interface Shoe

## Truly Wireless Connection

The UWP-D wireless microphone series and SMAD-P3 multi-interface shoe adapter. Together they work smarter.

Transmit audio signals from the wireless receiver to the camera with no need for connecting cables

The wireless receiver can be powered directly by the camera, eliminating the need for batteries



[www.pro.sony.eu/uwpd](http://www.pro.sony.eu/uwpd)

 @SonyProEurope / [www.twitter.com/sonyproeurope](https://www.twitter.com/sonyproeurope)

 /SonyProfessionalEurope

For full compatibility please check [www.pro.sony.eu/smadv3](http://www.pro.sony.eu/smadv3)