



# ASUS<sup>®</sup>

## VB199

1




2




2


A







B




C





3



VB199T / VB199S




VB199N / VB199D




3

MENU



4

-5°~20°



#### ASUS CONTACT INFORMATION

##### ASUSTeK Computer Inc.

Address 15 Li-Te Rd., Peitou,  
Taipei 11259, Taiwan  
Telephone +886-2-2894-3447  
Fax +886-2-2894-7798  
E-mail [info@asus.com.tw](mailto:info@asus.com.tw)  
Website <http://www.asus.com.tw/>

##### ASUS Computer International (America)

Address 800 Corporate Way,  
Fremont, CA 94539, USA  
Fax +1-510-608-4555  
Website <http://usa.asus.com/>

##### ASUS Computer GmbH (Germany and Austria)

Address Harkortstr. 21-23  
D-40880 Ratingen, Germany  
Telephone +49-1805-010920  
Website <http://www.asus.de/>  
Online Contact <http://www.asus.de/sales>

##### Technical Support

Telephone +86-21-38429911

##### Technical Support

Telephone +1-812-282-2787 (English Only)  
+1-905-370-2787 (French Only)  
Online Support <http://support.asus.com/>

##### Technical Support

Telephone +49-1805-010923  
Support Fax +49-2102-959911  
Online Support <http://support.asus.com/>