

INSTALLATION INSTRUCTIONS

SSB-570, SSM-570, SLB-570 and SLM-570 Interface Brackets


SSB-570, SSM-570, SLB-570 and SLM-570 Interface Brackets are designed for use with Chief® Series Projector Mounts. See the specific installation instructions provided with the mount for additional installation information.

Unpack carton and verify kit contents. If any listed parts are missing, immediately contact a Chief Customer Service representative.



WARNING: IMPROPER INSTALLATION CAN LEAD TO EQUIPMENT FALLING CAUSING SERIOUS PERSONAL INJURY AND DAMAGE TO EQUIPMENT! DO NOT substitute hardware. Use only hardware supplied by manufacturer!

- | | |
|--|---|
| (1) Interface Bracket | (2) Screw, Phillips Pan Head, Machine, M4 x 25mm**** |
| (4) 10 - 24 Thumb Nuts** | (1) Screw, Phillips Flat Head, Machine, M4 x 25mm**** |
| (1) All-Points Security Kit | (1) Screw, Phillips Pan Head, Machine, M4 x 20mm**** |
| (3) 1/2" x .194" x 1/2" Round Spacer**** | (3) Washer, Flat, M4 |
| (1) 1/2" x .218" x 1/4" Round Spacer**** | |



Only used when installing SLB/SSB interface brackets. **Used when mounting surface of projector is recessed.

NOTE: Specific to SSB-style and SSM-style interface bracket installation, all appropriate screws come pre-installed as reflected in the encircled locations above. DO NOT attempt to substitute and USE ONLY this pre-installed hardware for SSB-style and SSM-style interface bracket installation.

Installation Instructions



WARNING: OVER TIGHTENING OF SCREWS CAN DAMAGE PARTS AND CAN LEAD TO SERIOUS PERSONAL INJURY AND DAMAGE TO EQUIPMENT! DO NOT over tighten screws when installing interface bracket.

NOTE: Step 1 is only required when installing an SLB/SSB interface bracket. If an SLM/SSM bracket is being installed, proceed to step 2.

1. Screw thumb screws onto 10-24 x 5/8" Phillips pan head screws. DO NOT fully tighten thumb screws at this time.
2. Turn projector upside down on a flat surface.
3. Place three 1/2" and one 1/4" spacers over four threaded inserts in bottom of projector so heights are equal.
4. Place interface bracket onto bottom of projector and align spacers with mounting holes.
5. Using an M4 x 20mm Phillips pan head screw, an M4 x 25mm Phillips flat head screw and two M4 x 25mm Phillips pan head screws, attach interface bracket to projector. Tighten all fasteners at this time, securing the bracket to the projector.

NOTE: Security Screws can be substituted when mounting interface bracket to projector by using the parts and installation instructions in the All-Points Security Kit.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.



Milestone AV Technologies, and its affiliated corporations and subsidiaries (collectively, "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.



Our Mounts. Your Vision.

Chief Manufacturing, a products division of Milestone AV Technologies
8401 Eagle Creek Parkway, Savage, MN 55378
• P: 800.582.6480 / 952.894.6280 • F: 877.894.6918 / 952.894.6918

8850-000183 RevB
©2009 Milestone AV Technologies,
a Duchossois Group Company

05/09