



INSTALLATION INSTRUCTIONS

SLB-770 HANGER BRACKET


for EPSON EMP-7700p, EMP-7600p, EMP-5600p

Prior to assembly, unpack carton and verify contents.

For security installation, use security hardware package inside the ALL-POINTSTM Security Kit. Follow the instructions below for attaching the bracket to the projector using either standard hardware or security hardware.

If you are missing any of the following components, please contact Customer Service at 1-800-582-6480

(1)	SLB-770 Bracket	(4)	M4 - 20mm Screws
(5)	10 - 24 Thumb Nuts	(4)	M4 Flatwashers
(4)	½" x .194" x ½" Nylon Spacers		



INSTALLATION INSTRUCTIONS

1. Turn projector upside down.
2. Place the four ½" nylon spacers over the four threaded inserts in the bottom of the projector and place the SLB-770 bracket on top of the four ½" nylon spacers on the bottom of the projector lining up the four mounting holes in the SLB-770 bracket with the four ½" nylon spacers sitting on the bottom of the projector and secure using the four M4 -20mm mounting screws and M4 Flatwashers. **CAUTION: When attaching the mount be careful not to overtighten screws.**
3. See RPA and/or Smart-LiftTM Instructions.