

QuickLink

Diagram illustrating the QuickLink connection. A cable connects the projector to a USB drive. Below, a screenshot of the projector's menu shows 'Folder View' selected.

Wifi display Miracast compatible
(PPX 4350 Wireless / PPX 4350 Explorer)

Diagram illustrating the Wifi display connection. A cable connects the projector to a USB drive. Below, two screenshots of the projector's menu show 'Source' and 'Wifi Display' options.

MHL cable

PPA 1240 MHL Cable (with USB to Mini-USB adapter)

Diagram illustrating the MHL cable connection. A cable connects the projector to a Samsung Galaxy adapter (5pin to 11pin), which is then connected to a smartphone.

Micro SD Card

Diagram illustrating the Micro SD Card connection. A Micro SD card is inserted into the projector's slot. Below, a screenshot of the projector's menu shows 'Folder View' selected.

Bluetooth

Two screenshots of the projector's menu. The top one shows 'Settings' selected, and the bottom one shows 'Bluetooth' selected in the settings menu.

Mini display port

PPA 1270 Mini DisplayPort cable

Diagram illustrating the Mini display port connection. A cable connects the projector to a laptop. Below, a screenshot of the projector's menu shows 'Source' selected, and a photo of the projector displaying content.



Quick Start Guide

Always there to help you

Register your product for further support at www.philips.com/support



PHILIPS PicoPix

Warranty Card PHILIPS

Quick Start Guide PHILIPS

PPX 4350 Wireless

PPX 4350 Explorer

PPA I240 MHL Cable (with USB to Mini-USB adapter)

PPA I270 Mini DisplayPort cable

Power Supply

PPA 6200/EU PPA 6200/UK PPA 6200/US

1

PHILIPS PicoPix

PHILIPS PicoPix

2

PHILIPS PicoPix

HDMI

PHILIPS PicoPix

iPhone / iPad

PHILIPS PicoPix



www.facebook.com/PicoPix

Sagemcom Documents SAS
 250 Route de L'Empereur
 92848 Rueil-Malmaison Cedex
 FRANCE
 Tel : +33 (0)1 57 61 10 00 · Fax : +33 (0)1 57 61 10 01
www.sagemcom.com

PHILIPS and the PHILIPS' Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used by Sagemcom under license from Koninklijke Philips N.V.

© 2014 Sagemcom Austria GmbH
 All rights reserved

PPX4350
 Quick Start
 253610842-A