

Philips
Pouch

for shavers S5xxx-S7xxx-S9xxx

CP9062

A pouch to safely store your shaver.

This plastic pouch allows you to hygienically store your shaving device. The bag is also useful for taking your shaver with you when you're on the move.

PHILIPS

Specifications

Replaceable part

- Fits product type: S5400/41, S5620/12, S5620/41, S9021/12, S9021/13, S9031/12, S9031/13, S9031/26, S9031/27, S9041/12, S9041/13, S9111/12, S9111/26, S9111/31, S9111/32, S9111/41, S9111/42, S9112/43, S9151/31, S9151/41, S9151/42, S9161/31, S9161/32, S9161/41, S9161/42, S9171/31, S9171/32, S9181/13, S9511/31, S9511/32, S9511/41, S9511/42, S9511/63, S9521/31, S9521/32, S9521/41, S9711/31, S9711/32, S9911/10, S9911/11, S9911/33, S9911/62, S9988/68, S5008, S5010, S5011, S5013, S5015, S5050, S5070, S5075, S5077, S5078, S5079, S5080, S5081, S5420/04, S5420/06, S5420/08, S5510/37, S5510/45, S5520/45, S5600/12, S5600/41, S5085, S5205, S5290, S5355, S7310, S7311, S7320, S7370, S7510, S7520, S7530, S7550, S7710, S8950, S9090, S9181, S9182, S9512, S9522, S9988, S5090, S5095, S5210, S5211, S5230, S5270, S5271, S5340, S5360, S5370, S5380, S5390, S5391
- Fits product types: S9021, S9031, S9041, S9111, S9112, S9121, S9151, S9152, S9161, S9171, S9311, S9321, S9371, S9511, S9521, S9522, S9531, S9711, S9712, S9721, S9731, S9911
- Fits product family: S5082, S5086, S5091, S5212, S5213, S5231, S5251, S5252, S5272, S5273, S5290, S5335, S5355, S5395, S5396, S7310, S7320, S7371, S7510, S7521, S7522, S7530, S7550, S7720, S7920, S8860, S8880, S8980, S9211, SP9811, SP9851
- Fits product type: S5100, S5110, S5130, S5140, S5600, S5610, S5620, S5082, S5085, S5090, S5095, S7720, S7780, S7920, S9021, S9031, S9041, S9051, S9111, S9112, S9121, S9151, S9152, S9161, S9171, S9181, S9182, S9185, S9186, S9311, S9321, S9371, S9511, S9512, S9521, S9522, S9531, S9551, S9552, S9711, S9712, S9721, S9731, S9732, S9741, S9751, S9781, S9911, S9981, S9988, S5290, S5571, S7310, S7311, S7312, S7320, S7330, S7370, S7510, S7520, S7530, S7540, S7550
- Fits shaver type: S7310, S7311, S7320, S7340, S7350, S7360, S7370, S7371, S7510, S7520, S7521, S7522, S7530, S7550, S7560, S7561, S7710, S7720, S7730, S7740, S7780, S7920, S7921, S7980, S8950, S8960, S8980, S9031, S9041, S9051, S9090, S9091, S9111, S9112, S9131, S9151, S9161, S9171, S9181, S9185, S9186, S9211, S9311, S9521, S9531, S9551, S9552, S9711, S9721, S9732, S9733, S9741, S9751, S9781, S9911, SP9820, SP9821, SW5700, SW5710, SW5720, SW6700, SW6710, SW9700, S5672, S5008, S5010, S5011, S5013, S5015, S5040, S5050, S5051, S5070, S5071, S5072, S5073, S5074, S5075, S5076, S5077, S5078, S5079, S5080, S5081, S5082, S5083, S5085, S5086, S5090, S5091, S5095, S5100, S5110, S5120, S5130, S5140, S5150, S5205, S5210, S5211, S5212, S5213, S5214, S5215, S5216, S5230, S5231, S5240, S5250, S5251, S5252, S5270, S5271, S5272, S5273, S5290, S5310, S5320, S5330, S5340, S5351, S5355, S5360, S5361, S5370, S5380, S5390, S5391, S5395, S5396, S5397, S5400, S5420, S5510, S5520, S5530, S5540, S5550, S5551, S5560, S5570, S5571, S5572, S5580, S5590, S5600, S5610, S5620, S5630, S5640, S5650, S5651, S5660, S5670



Issue date 2023-09-14

Version: 6.6.1

EAN: 87 10103 70806 3

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com