

Quick Start >>



Cloud Camera

See more · Be sure

Connect the camera to the network your smartphone is on.





0

Smartphone requirement Android 3.0 or higher iOS 7.0 or higher 2

Download and install the tpCamera app.











3

Launch tpCamera, log into your TP-LINK Cloud account or create one, then follow the app instructions to set up your new camera.







Unscrew the camera head.



```
Remove the base cover.
```



Use two screws to secure the base.



Put the base cover and camera head back on.

about TP-LINK Cloud Camera.

7106505940 REV1.0.1 ©2015 TP-LINK

Via Smartphone:

On the **My Cam** screen, tap your camera to view the live video.



Via Computer:

Log into the TP-LINK Cloud website (https://www.tplinkcloud.com), and click your camera to view the live video.



How to use the WPS/RESET Button

WPS (Wi-Fi Protected Setup):

If your Wi-Fi router supports WPS, you can connect the camera to your Wi-Fi network using WPS. For details, see the camera's User Guide.

Reset:

① Note

Resetting a registered camera will remove it from your TP-LINK Cloud account.



While the camera is powered on, press the **WPS/RESET** button for **5** seconds until the System LED on the front panel goes off. The camera will reset and reboot.

Get more with the camera

Get notifications when motion is detected

Log into the web management page of your camera to set Motion Detection and Notification Delivery. For details and more advanced configurations, see the camera's User Guide.

View all of your cameras on one screen

Download and install the TP-LINK Camera Control utility to view and manage multiple cameras on one screen. For details, see the Camera Control User Guide.

Downloads

For related user guides, Camera Control utility, camera firmware, and other supports, please visit the product page at http://www.tp-link.com.

