


Motherboard

N3050T

- quick start guide
- دليل التشغيل السريع
- Кратко упу̀тване за бърз старт
- Stručná příručka
- Quick Start-vejledning
- Snelstartgids
- Lühijuhend
- راهنمای شروع سریع
- Guide de démarrage rapide
- Pikakäynnistysopas
- Schnellstarthilfe
- Οδηγός γρήγορης έναρξης
- Beüzemelési útmutató
- Guida Rapida
- Panduan Ringkas
- クイックスタートガイド
- Жылдам іске қосу нұсқаулығы
- 빠른 시작 설명서
- Greitos darbo pradžios vadovas
- Īsa pamācība
- Hurtigstartsveiledning
- Guia de consulta rápida
- Instrukcja szybkiej instalacji
- Краткое руководство
- Ghid de pornire rapidă
- Guia de início rápida
- Vodič za brzo korišćenje
- Stručný návod na spustenie
- Snabbstartsguide
- คู่มือเริ่มต้นอย่างเร็ว
- Hızlı Başlatma Kılavuzu
- Hướng dẫn khởi động nhanh
- vodič za brzi početak rada

Motherboard Layout



Australia statement notice

From 1 January 2012 updated warranties apply to all ASUS products, consistent with the Australian Consumer Law. For the latest product warranty details please visit <http://support.asus.com>. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

If you require assistance please call ASUS Customer Service 1300 2787 88 or visit us at <http://support.asus.com>

India E-waste (Management and handling) Rule 2011


This product complies with the "India E-waste (Management and Handling)Rule 2011" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls(PBBs) and polybrominated diphenyl ethers (PBDEs) in concentrations exceeding 0.1 % by weight in homogenous materials and 0.01 % by weight in homogenous materials for cadmium, except for the exemptions listed in Schedule-II of the Rule

AEEE Yönetmeliğine Uygundur




Step 1

- Install memory modules
- تثبيت وحدات الذاكرة
- Інсталируйте модуліте пам'яті
- Instalace paměťových modulů
- Installer hukommelsesmodulerne
- Geheugenmodules installeren
- Paigaldage mäluoodulid
- مادول های حافظه را نصب کنید
- Installer les modules mémoire
- Asenna muistimoduulit
- Installieren der Speichermodule
- Εγκατάσταση των στοιχείων μνήμης
- Helyezze be a memória modulokat
- Installare i moduli di memoria
- Pasang modul memori
- メモリーモジュールを設置する
- Жад модульдерін орнатыңыз



Step 3


- Install expansion card(s)
- تثبيت بطاقة (بطاقات) التوسعة
- Інсталируйте допълнителна карта (допълнителни карти)
- Instalace přídatné karty (karet)
- Installer udvidelseskortene
- Uitbreidingskaart(en) installeren
- Paigaldage laienduskaart(-kaardid)
- کارت های گسترش را نصب کنید
- Installer une carte d'extension
- Asenna laajennuskortti/kortit
- Installieren der Erweiterungskarte(n)
- Εγκατάσταση καρτών επέκτασης
- Helyezze be a bővítőkérttyá(ka)t
- Installare le schede di espansione
- Pasang kartu ekspansi
- 拡張カードを設置する
- Кеңейту картас(лар)ын орнатыңыз
- 확장 카드 설치
- Sumontuokite išplėtimo plokštę (-es)
- Uzstādiet izvērses karti(-es)
- Installer utvidelseskort
- Instale placas de expansão
- Instalacja kart(y) rozszerzenia
- Установка карт расширения
- Instalați cardul/cardurile de expansie
- Instalar tarjetas de expansión
- Instalirajte ekspanzionu/e karticu/e
- Inštalácia rozširujúcich kariet
- Installera expansionskort
- ติดตั้งเลือกซ์แพนชั่นการ์ด
- Genişletme kartlarını takın
- Lắp (các) thẻ mở rộng
- Instalacija kartica za proširenje



- 메모리 모듈 설치
- Sumontuokite atminties modulius
- Uzstādiet atmiņas moduļus
- Installer minnemoduler
- Instale módulos de memória
- Instalacja modułów pamięci
- Установка модулей памяти
- Instalați modulele de memorie
- Instalar los módulos de memoria
- Instalirajte module memorije
- Inštalácia pamäťových modulov
- Installera minnesmoduler
- ติดตั้งโมดูลหน่วยความจำ
- Bellek modüllerini takın
- Lắp các thanh nhớ
- Instalacija memorijskih modula


Step 2

- Install SATA devices
- تثبيت أجهزة SATA
- Інсталируйте SATA устройства
- Instalace zařízení SATA
- Installer SATA-udstyret
- SATA-apparaten installeren
- Paigaldage SATA seadmed
- دستگاه های SATA را نصب کنید
- Installer des périphériques SATA
- Asenna SATA-laitteet
- Installieren der SATA-Geräte
- Εγκατάσταση συσκευών SATA
- Szerelje be a SATA eszközöket
- Installare i dispozitivi SATA
- Pasang perangkat SATA
- SATA デバイスを取り付ける
- SATA құрылғыларын орнатыңыз




Step 4

- Install system panel connectors
- تثبيت وحدات توصيل لوحة النظام
- Інсталируйте конекторите на ситемния панел
- Instalace konektorů panelu systému
- Installer systempanelets tilslutninger
- Aansluitingen op het systeempaneel installeren
- Paigaldage süsteemi paneeli konnektorid
- رابط های صفحه سیستم را نصب کنید
- Installer les connecteurs système
- Asenna järjestelmäpaneelin liittimet
- Installieren des Systemtafelanschlusses
- Εγκατάσταση συνδέσμων πάνελ συστήματος
- Szerelje be a rendszerpanel csatlakozót
- Installare i connettori del pannello del sistema
- Pasang konektor panel sistem
- システムパネルコネクタを取り付ける
- Жүйе тақтасының қосқыштарын орнатыңыз
- 시스템 패널 커넥터 설치
- Sumontuokite sistemos plokštės jungtis
- Uzstādiet sistēmas paneļa savienotājus
- Installer kontakter for systempanelet
- Instale os conectores do painel do sistema
- Instalacja złączy panela systemu
- Установка соединений системной панели
- Instalați conectorii pentru placa de bază
- Instalar conectores del panel del sistema
- Instalirajte sistemske priključke
- Inštalácia konektorov ovládacieho panela
- Installera systempanelkontakter
- ติดตั้งข้อต่อแผงระบบ
- Sistem paneli konnektörlerini takın
- Lắp các đầu nối hệ thống ra ngoài
- Instalacija konektora ploče sustava





Step 5

Install power connectors
ATX تثبيت توصيلات الطاقة
Инсталируйте конекторите за хранване
Instalace konektorů napájení
Installer strømtilslutningerne
Voedingsaansluitingen installeren
Paigaldage i toitekonnektorid
رابط های برق ATX را نصب کنید
Installer les connecteurs d'alimentation
Asenna virtaliittimet
Installieren des Stromanschlusses
Εγκατάσταση συνδέσμων τροφοδοσίας
Csatlakoztassa az tápcsatlakozókat
Installare i connettori di alimentazione
Pasang konektor daya
電源コネクターを取り付ける
АТХ электр қуат қосқыштарын орнатыңыз
전원 커넥터 설치
Sumontuokite maitinimo jungtis
Uzstādiet strāvas savienotājus
Installer kontakter for strøm
Instale os conectores de alimentação
Instalacja złączy zasilacza
Установка разъема
Instalați pinii conectori
Instalar conectores de alimentación
Instalirajte električne priključke
Inštalácia napájacích konektorov
Installera strömkontakter
ติดตั้งขั้วต่อ เพาเวอร์
Güç konnektörlerini takın
Lắp các đầu nối nguồn
Instalacija konektora napajanja




Step 7

Power on the system and install operating system and drivers
تشغيل الجهاز وتنشيط نظام وبرمجيات التشغيل
Включите системата и инсталирайте операционната система и драйверите
Zapnutí napájení systému a instalace operačního systému a ovladačů
Tænd for systemet, og installer operativsystemet og de tilhørende drivere
Het systeem inschakelen en het besturingssysteem en de stuurprogramma's installeren
Lülitage süsteemi toide sisse ning installige operatsioonisüsteem ja draiverid
سیستم را روشن کرده و درایورها و سیستم عامل را نصب کنید
Allumer le système et installer le système d'exploitation et les pilotes
Käynnistä järjestelmä ja asenna käyttöjärjestelmä ja ohjaimet
Einschalten des Systems und installieren des Betriebssystems und der Treiber
Ενεργοποιήστε το σύστημα και εγκαταστήστε το λειτουργικό σύστημα και τα προγράμματα οδήγησης
Kapcsolja be a rendszert és telepítse az operációs rendszert és illesztőprogramokat
Accendere il sistema e installare il sistema operativo e i driver
Hidupkan sistem, lalu instal sistem operasi dan driver
システムの電源をONにし、OSとドライバーをインストールする
Жүйені қосып, операциялық жүйені және драйверлерді орнатыңыз
시스템 전원 켜기 및 운영체제와 드라이버 설치
Įjunkite sistemą ir įdiekite operacinę sistemą ir tvarkykles
Ieslēdziet sistēmu un instalējiet operētājsistēmu un draiverus
Slå på systemet og installer operativsystem og drivere
Ligue o sistema e instale o sistema operativo e os controladores
Włącz zasilanie i zainstaluj system operacyjny oraz sterowniki
Включение системы и установка операционной системы и драйверов
Porniți sistemul și instalați sistemul de operare și driverele
Proporcionar alimentación al sistema e instalar el sistema operativo y los controladores
Uključite sistem i instalirajte operativni sistem i drajvere
Zapnutie systému a inštalácia operačného systému a ovládačov
Slå på systemet och installera operativsystem och drivrutiner
เปิดระบบ และติดตั้งระบบปฏิบัติการและไดรเวอร์
Sistemi açıp işletim sistemini ve sürücülerini yükleyin
Bật nguồn hệ thống và cài đặt hệ điều hành cũng như các driver
Uključivanje sustava i instaliranje operativnih sustava i upravljačkih programa



Step 6

Connect input/output devices
توصيل أجهزة الدخّل/الخروج
Свързване на I/O устройства
Připojení vstupních/výstupních zařízení
Tilslut input-/outputudstyr
I/O-apparaten aansluiten
Ühendage sisend -/väljundseadmed
دستگاه های ورودی/خروجی را متصل نمایید
Connecter les périphériques d'entrée/sortie
Liitä tulo/lähtölaitteita
Eingabe-/Ausgabe-Geräte verbinden
Σύνδεση συσκευών εισόδου/εξόδου
Bemeneti/kimeneti eszközök csatlakoztatása
Collegate i dispositivi di input/output
Sambungkan perangkat input/output
入出デバイスに接続する
Кіріс/шығыс құрылғыларын қосу



입력/출력 장치 연결
Prijunkite įvesties / išvesties įrenginius
Pievienot ievades/izvades ierīces
Koble til inngang/utgangsenheter.
Ligar dispositivos de entrada/saída
Podłączenie urządzeń wejścia/wyjścia
Подключите устройства ввода/вывода
Conectare dispozitive de intrare/ieșire
Conectar dispositivos de entrada y salida
Povežite ulazne/izlazne uređaje
Pripojenie vstupných/výstupných zariadení
Anslut ingående/utgående enheter
เชื่อมต่ออุปกรณ์อินพุต/เอาต์พุต
Giriş/çıkış aygıtlarına bağlan
Kết nối các thiết bị đầu vào/đầu ra
Spajanje ulaznih/izlaznih uređaja