


Philips  
Water container

- Check before ordering
- Type plate bottom appliance
- This part is only suitable for
- /B

CP0278/01



For water storage in your SENSEO® coffee machine

Please check specifications for compatible product

A water container should be cleaned regularly. Whenever that's the case, you'll be happy not to miss your coffee moment and to have an extra reservoir for your SENSEO® coffee machine. The tank contains 0.9 liter, for six cups of coffee.

**Ease of using Philips spare parts**

- Easy renew your product with original Philips parts

**PHILIPS**

## Water container

Check before ordering Type plate bottom appliance, This part is only suitable for, /B

CP0278/01

# Specifications

### Replaceable part

- Fits product types: HD7825/30, HD7825/31, HD7825/70
- Fits product types:: HD7825/61
- Fits product types: HD7825/60, HD7825/62

- Fits product type: HD7825/65, HD7825/66, HD7825/68, HD7825/69, HD7825/73, HD7828/50, HD7828/51, HD7828/59, HD7821/6x, HD7825/01, HD7825/23, HD7826/21, HD7828/53

# Highlights

### Easy renew of product parts

From time to time your product needs a facelift but it was never so easy like with Philips consumer replacement parts to renew your product. This all with guaranteed Philips quality.



Issue date 2016-06-26

Version: 1.0.1

© 2016 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)