

### Philips Water container

- Check before ordering
- Type plate bottom appliance
- This part is only suitable for
- /B

## CP0277/01

## Water container

## Check specifications tab for compatible products

This water container is easily detachable for refilling and contains 0.9 litre. Clean the water container regularly to avoid malfunction. Compatible with SENSEO $^{(\!R\!)}$  Viva Café version "/B"; see type plate.

### Ease of using Philips spare parts

• Easily renew your product with original Philips parts



Check before ordering Type plate bottom appliance, This part is only suitable for, /B

## Specifications

Suitable for:
• SENSEO® Viva Cafe: HD7821, HD7828, HD7829, HD7831, HD7833, HD7836, HD7825, HD6561,

HD6563, HD6569, HD6564, HD6565, HD6566, HD6567, HD6560

# Highlights

#### Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.



Issue date 2022-12-23

Version: 4.4.1

© 2022 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com