



# Replace your current on/off knob

This knob is needed for turning your Airfryer on and off.

### Ease of using Philips spare parts

• Easily renew your product with original Philips parts

### Highlights

#### Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

## Specifications

Replaceable part

Fits product family: HD972x/xx, HD962x

© 2020 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2020-12-11 Version: 4.0.1

EAN: 08 71010 37895 67

www.philips.com

