

LIMITED WARRANTY

The Little Tikes Company makes fun, high quality toys. We warrant to the original purchaser that this product is free of defects in materials or workmanship for one year from the date of purchase (dated sales receipt is required for proof of purchase). At the sole election of The Little Tikes Company, the only remedy available under this warranty will be the replacement of the defective part or replacement of the product. This warranty is valid only if the product has been assembled and maintained per the instructions. This warranty does not cover abuse, accident, cosmetic issues such as fading or scratches from normal wear, or any other cause not arising from defects in material and workmanship.

U.S.A and Canada: For warranty service or replacement part information, please visit our website at www.littletikes.com, call 1-800-321-0183 or write to: Consumer Service, The Little Tikes Company, 2180 Barlow Road, Hudson OH 44236, U.S.A. Some replacement parts may be available for purchase after warranty expires contact us for details.

Outside U.S.A and Canada: Contact place of purchase for warranty service. This warranty gives you specific legal rights, and you may also have other rights, which vary from country/state to country/state. Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This product is not intended for daycare or commercial use.



little tikes®

Learn to Pedal 3-in-1 Trike

Ages: 18-36 Months

634031C

ADULT ASSEMBLY AND SUPERVISION REQUIRED



Please keep this manual as it contains important information.



© The Little Tikes Company,
an MGA Entertainment company.
LITTLE TIKES® is a trademark of Little Tikes in the U.S. and other
countries. All logos, names, characters, likenesses, images, slogans, and
packaging appearance are the property of Little Tikes.
Little Tikes Consumer Service
2180 Barlow Road
Hudson, Ohio 44236 U.S.A.
1-800-321-0183
Printed in China

little tikes®

Visit our website at
www.littletikes.com
to register your product and
to enter our sweepstakes.
(No purchase necessary)

www.littletikes.com



PLEASE READ INSTRUCTIONS
BEFORE ASSEMBLING AND OPERATING.

Age: 18-36 months

Please save sales receipt for proof of purchase.

⚠ WARNING: ADULT ASSEMBLY REQUIRED.

Read entire instructions carefully before assembling this product.

⚠ WARNING: ASSEMBLY

- Keep these instructions for future reference.
- Prior to assembly, this package contains small parts. The parts (including hardware) are choking hazards and may contain sharp edges and points. Keep away from children until assembled.
- Ensure working area is free of danger, always dispose of packaging material in such a way that it may not cause any harm. Plastic bags can be dangerous. To avoid suffocation keep plastic bags away from babies and children.
- To prevent serious injury, children must not use the equipment until completely assembled.
- This product is intended for outdoor domestic family use only.
- This product is for private, residential use only (no commercial or public use).
- Adult assembly required choking hazard to children under the age of 3 years - contains small parts prior to assembly.

ASSEMBLY HINT

IMPORTANT: Assemble all parts together loosely at first. Check that assembly is correct then tighten locknut and screws.

⚠ WARNING: TO AVOID SERIOUS INJURY:

- Continuous adult supervision required.
- When assembling STAGE ONE and STAGE TWO of the tricycle, the backrest must be re-attached before allowing a child to ride the tricycle.
- Never use near motor vehicles.
- Never use near streets, swimming pools, hills, steps, or sloped driveways.
- Always wear closed shoes when using the tricycle.
- Never allow more than one rider on the tricycle.
- Instruct children on proper use of this product before allowing them to ride.
- This product is not to be used in a manner other than for which it is intended.
- It is recommended that rider always wear a properly fitted helmet that complies with U. S. Consumer Product Safety Commission (CPSC) standard 16 CFR 1203.
- Ride-on toys should be used with caution since skill is required in order to avoid falls or collisions which may cause injury to the user or third parties.

⚠ WARNING! Not to be used by children over the age of 36 months due to size limitation.

- Maximum child's weight: 50 lbs. (23 kg).
- Safeguard the product against rolling away when parking it.

MAINTENANCE & CLEANING








- Check all hardware during usage period and tighten as required. It is particularly important that this procedure be followed at the beginning of each season. If these checks are not carried out, the toy could overturn or otherwise become a hazard. Replacement should be made in accordance with the manufacturer's instructions.
- Do not attempt to modify or repair this product. For help contact Little Tikes Consumer Service.
- Clean trike with a slightly damp cloth (cold water) and mild soap. Never use a corrosive or abrasive substance to clean the product.

DISPOSAL

- Disassemble and dispose of equipment in such a manner that no hazardous conditions, such as but not limited to, small parts and sharp edges, exist at the time equipment is discarded.


REMOVING SEATBELT

(Optional Stage Three)




STAGE THREE


A




Remove latch. See illustrations 10-12.



B




C




ASSEMBLY PARTS FOR STEP #1 BELOW

NOTE: Pages 3-8 show assembly for Stage One Trike.
See Pages 9-10 for Stage Two and Stage Three Trikes.





1



M2 x 4




2




3



4




5




STAGE TWO


A






B



C








D




Leave Hub OUT to disengage pedals.


STAGE ONE




6




7











8



9





Learn to Pedal 3-in-1 Trike

Your Little Tikes® Learn to Pedal 3-in-1 Trike was created to grow right along with your child.

IN STAGE ONE

- The seat is in a forward position to allow more comfort to the child.
- A backrest and seat belt are installed for safety.
- The pedals and handlebars of the trike are unlocked so that the child cannot pedal or steer and the adult has all the control.

IN STAGE TWO

- The seat is in the middle position to allow more room for legs which have grown a bit.
- A backrest and seatbelt are installed for safety.
- The pedals are unlocked and the handlebars of the trike are locked so that, as the adult pushes, the child can pedal and steer.

IN STAGE THREE

- The seat is in the farthest position back from the pedals to allow more comfort to the older child.
- The push handle, backrest, and seat belt have been removed for the older child.
- The pedals and handlebars of the trike are locked allowing the child full control of the trike.

Have a look at the next few pages and you will find that changing stages is simple, takes just a few minutes, and guarantees many months of fun and comfort for both you and your child.