

#### Always there to help you Register your product and get support at www.philips.com/support



Quick Start Guide

# PX840T

**PHILIPS** 

## Safety

- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Do not block any ventilation openings. The minimum distance around the product for sufficient ventilation is 10 cm.
- Use only power supplies listed in the user manual.
- Battery usage CAUTION To prevent battery leakage which may result in bodily injury, property damage, or damage to the product:
  - Install all batteries correctly, + and as marked on the
  - Do not mix batteries (old and new or carbon and
  - Batteries (packed or installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
  - Remove batteries when the product is not used for a
  - Batteries contain chemical substances, so they should be disposed of properly.
- The product shall not be exposed to dripping or splashing.
- Use the product in moderate climate.
- Do not place any sources of danger on the product (e.g. liquid filled objects, lighted candles).
- Where the plug of the Direct Plug-in Adapter is used as the disconnect device, the disconnect device shall remain readily



Note

The type plate is located on the bottom of the product.

## Notice

Any changes or modifications made to this device that are not expressly approved by Gibson Innovations may void the user's authority to operate the equipment.

#### Compliance

Hereby, Gibson Innovations declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. You can find the Declaration of Conformity on www.philips.com/support.

#### Care of the environment

Disposal of your old product



Your product is designed and manufactured with high quality




This symbol on a product means that the product is covered by European Directive 2012/19/EU. Inform yourself about the local separate collection system for electrical and electronic products. Follow local rules and never dispose of the product with normal household waste. Correct disposal of old products helps prevent negative consequences for the environment and human health.

### **Bluetooth**

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Gibson  $\,$ Innovations Limited is under license. Other trademarks and trade names are those of their respective owners.

This apparatus includes this label:




## **Specifications**


Power supply	
- AC power (Power Adapter A)	Brand name: PHILIPS;
	Model: HB40-1203001SPA;
	Input: AC 100-240 V~, 50/60 Hz, 0.8 A
	Output: DC 12V === 3000 mA;
- AC power (Power Adapter B)	Brand name: PHILIPS;
	Model: GME36A-120300FBR;
	Input: 100-240 V~, 50-60 Hz, 1.2 A
	Output: 12 V === 3 A;
- Battery	8 X 1.5V D/R20 CELL/UM1 batteries (not supplied)
Operation Power Consumption	20 W
Eco Standby Power Consumption	<0.5 W


This product has been manufactured by, and is sold under the responsibility of Gibson Innovations Ltd., and Gibson Innovations Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license


PX840T\_05\_QSG\_V3.0












































**(** 



