

Inspiron 15 Gaming Setup and Specifications

Computer Model: Inspiron 15-7566
Regulatory Model: P65F
Regulatory Type: P65F001



Notes, cautions, and warnings



NOTE: A NOTE indicates important information that helps you make better use of your computer.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

© 2016 Dell Inc. All rights reserved. This product is protected by U.S. and international copyright and intellectual property laws. Dell and the Dell logo are trademarks of Dell Inc. in the United States and/or other jurisdictions. All other marks and names mentioned herein may be trademarks of their respective companies.

2016 - 08

Rev. A00

Contents

Set up your computer.....	5
Views.....	8
Front.....	8
Left.....	8
Right.....	9
Base.....	10
Display.....	11
Specifications.....	13
Dimensions and weight.....	13
System information.....	13
Memory.....	13
Ports and connectors.....	14
Communications.....	14
Audio.....	14
Storage.....	15
Media-card reader.....	15
Keyboard.....	15
Camera.....	16
Touch pad.....	16
Power adapter.....	16
Battery.....	17
Display.....	17
Video.....	18
Computer environment.....	18
Keyboard shortcuts.....	19


Getting help and contacting Dell.....	21
Self-help resources.....	21
Contacting Dell.....	21

Set up your computer


- 1 Connect the power adapter and press the power button.



- 2 Follow the instructions on the screen to finish Windows setup:
a) Connect to a wireless network.



- b) Sign in to your Microsoft account or create a new account.



3 Locate Dell apps.



Register your computer


Dell Help & Support



SupportAssist — Check and update your computer

Views

Front



1 Power and battery-status light/hard-drive activity light

Indicates the battery-charge status or the hard-drive activity.

 **NOTE:** Press Fn+H to toggle this light between power and battery-status light and hard-drive activity light.

Hard-drive activity light

Turns on when the computer reads from or writes to the hard drive.

Power and battery-status light

Indicates the power and battery-charge status.

Solid white — Power adapter is connected and the battery has more than 5% charge.

Amber — Computer is running on battery and the battery has less than 5% charge.

Off

- Power adapter is connected and the battery is fully charged.
- Computer is running on battery and the battery has more than 5% charge.
- Computer is in sleep state, hibernation, or turned off.

Left



1 **Security-cable slot**

Connect a security cable to prevent unauthorized movement of your computer.

2 **Power-adapter port**

Connect a power adapter to provide power to your computer and charge the battery.


3 **USB 3.0 port**

Connect peripherals such as storage devices and printers. Provides data transfer speeds up to 5 Gbps.

4 **Media-card reader**

Reads from and writes to media cards.

Right



1 **Headset port**

Connect a headphone or a headset (headphone and microphone combo).

2 **USB 3.0 port**

Connect peripherals such as storage devices and printers. Provides data transfer speeds up to 5 Gbps.

3 **USB 3.0 port with PowerShare**

Connect peripherals such as storage devices and printers.

Provides data transfer speeds up to 5 Gbps. PowerShare enables you to charge your USB devices even when your computer is turned off.



NOTE: If your computer is turned off or in hibernate state, you must connect the power adapter to charge your devices using the PowerShare port. You must enable this feature in the BIOS setup program.



NOTE: Certain USB devices may not charge when the computer is turned off or in sleep state. In such cases, turn on the computer to charge the device.

4 **HDMI port**

Connect a TV or another HDMI-in enabled device. Provides video and audio output.

5 **Network port**

Connect an Ethernet (RJ45) cable from a router or a broadband modem for network or internet access.

Base



1 **Left-click area**

Press to left-click.

2 **Touch pad**

Move your finger on the touch pad to move the mouse pointer. Tap to left-click and two finger tap to right-click.

3 **Right-click area**

Press to right-click.

4 **Power button**


Press to turn on the computer if it is turned off, in sleep state, or in hibernate state.

Press to put the computer in sleep state if it is turned on.

Press and hold for 4 seconds to force shut-down the computer.

 **NOTE:** You can customize the power-button behavior in Power Options. For more information, see *Me and My Dell* at www.dell.com/support/manuals.

Display



- 1 Left microphone**
Provides digital sound input for audio recording and voice calls.
- 2 Infrared emitter (touch screen)**
Emits infrared light, which enables the infrared camera to sense depth and track motion.
- 3 Infrared camera (touch screen)**
Enables you to video chat, capture photos, and record videos. Depth-sensing feature of the camera enhances security when paired with Windows Hello.
- 4 Camera**
Enables you to video chat, capture photos, and record videos.
- 5 Camera-status light**
Turns on when the camera is in use.
- 6 Right microphone**

Provides digital sound input for audio recording and voice calls.

7 **Service Tag label**

The Service Tag is a unique alphanumeric identifier that enables Dell service technicians to identify the hardware components in your computer and access warranty information.

Specifications

Dimensions and weight

Height	25.3 mm (1 in)
Width	384.90 mm (15.15 in)
Depth	274.70 mm (10.81 in)
Weight (maximum)	<ul style="list-style-type: none">• Touch: 2.76 kg (6.08 lb)• Non-touch: 2.65 kg (5.84 lb)



NOTE: The weight of your computer varies depending on the configuration ordered and the manufacturing variability.

System information

Computer model	Inspiron 15-7566
Processor	6 th generation Intel Core i5/i7
Chipset	Intel HM170

Memory

Slots	Two SODIMM slots
Type	DDR4
Speed	2133 MHz
Configurations supported	4 GB, 8 GB, 16 GB, and 32 GB

Ports and connectors

External:

Network	One RJ-45 port
USB	<ul style="list-style-type: none">• One USB 3.0 port with PowerShare• Two USB 3.0 ports
Audio/Video	<ul style="list-style-type: none">• One HDMI port• One headset (headphone and microphone combo) port

Internal:

M.2 Card	<ul style="list-style-type: none">• One M.2 slot for SSD card• One M.2 slot for WiFi/Bluetooth
----------	---

Communications

Wireless	<ul style="list-style-type: none">• Wi-Fi 802.11 ac• Bluetooth 4.2• Miracast
----------	--

Audio

Controller	Realtek ALC3246 with Waves MaxxAudio Pro
Speakers	Two
Speaker output	<ul style="list-style-type: none">• Average: 2 W• Peak: 2.5 W
Subwoofer	One
Subwoofer output	<ul style="list-style-type: none">• Average: 3 W

Microphone

- Peak: 3.5 W

Digital-array microphones in camera assembly

Volume controls

Media-control shortcut keys

Storage

Interface

- SATA 6 Gbps
- PCIe/NVMe

Hard drive

One 2.5-inch drive (SATA)

Solid-state drive

One M.2 drive (SATA or PCIe/NVMe)

Media-card reader

Type

One 2-in-1 slot

Cards supported

- SD card
- MultiMedia Card (MMC)

Keyboard

Type

- Chiclet backlit keyboard (red/white)



NOTE: The red backlit keyboard is available only in specific regions.

- Non-backlit keyboard

Shortcut keys

Some keys on your keyboard have two symbols on them. These keys can be used to type alternate characters or to perform secondary functions. To type the alternate character, press Shift and the desired key. To perform secondary functions, press Fn and the desired key.



NOTE: You can define the primary behavior of the function keys (F1-F12) by changing **Function Key Behavior** in BIOS setup program.

[Keyboard shortcuts](#)

Camera

Resolution	<ul style="list-style-type: none">• Still image: 0.92 megapixel• Video: 1280 x 720 (HD) at 30 fps (maximum)
Diagonal viewing angle	74 degrees

Touch pad

Resolution	<ul style="list-style-type: none">• Horizontal: 1228• Vertical: 928
Dimensions	<ul style="list-style-type: none">• Height: 80 mm (3.15 in)• Width: 105 mm (4.13 in)

Power adapter

Type	130 W
Input voltage	100 VAC–240 VAC
Input frequency	50 Hz–60 Hz
Input current (maximum)	2.50 A
Output current (continuous)	6.70 A
Rated output voltage	19.50 VDC
Temperature range: Operating	0°C to 40°C (32°F to 104°F)
Temperature range: Storage	–40°C to 70°C (–40°F to 158°F)

Battery

Type	6-cell "smart" lithium ion (74 WHr)
Width	177.80 mm (7 in)
Depth	87.85 mm (3.46 in)
Height	11.30 mm (0.44 in)
Weight (maximum)	0.36 kg (0.79 lb)
Voltage	11.10 VDC
Charging time (approximate)	4 hours (when the computer is off)
Operating time	Varies depending on operating conditions and can significantly reduce under certain power-intensive conditions.
Life span (approximate)	300 discharge/charge cycles
Temperature range	<ul style="list-style-type: none">• Operating: 0°C to 35°C (32°F to 95°F)• Storage: -40°C to 65°C (-40°F to 149°F)
Coin-cell battery	CR-2032

Display

Type	15-inch FHD non-touch screen	15-inch FHD touch screen	15-inch UHD non-touch screen
Resolution (maximum)	1920 x 1080	1920 x 1080	3840 x 2160
Viewing angle (Left/Right/Up/Down)	40/40/10/30 degrees	80/80/80/80 degrees	80/80/80/80 degrees
Pixel pitch	0.179 mm	0.179 mm	0.090 mm
Height (excluding bezel)	193.59 mm (7.62 in)	193.59 mm (7.62 in)	194.40 mm (7.65 in)

Width (excluding bezel)	344.16 mm (13.55 in)	345.60 mm (13.61 in)
Diagonal (excluding bezel)	394.87 mm (15.55 in)	396.50 mm (15.61 in)
Refresh rate	60 Hz	
Operating angle	0 degree (closed) to 135 degrees	
Controls	Brightness can be controlled using shortcut keys	

Video

	Integrated	Discrete
Controller	Intel HD Graphics 530	NVIDIA GeForce GTX960M
Memory	Shared system memory	4 GB GDDR5

Computer environment

Airborne contaminant level: G1 as defined by ISA-S71.04-1985

	Operating	Storage
Temperature range	0°C to 35°C (32°F to 95°F)	-40°C to 65°C (-40°F to 149°F)
Relative humidity (maximum)	10% to 90% (non-condensing)	0% to 95% (non-condensing)
Vibration (maximum)*	0.66 GRMS	1.30 GRMS
Shock (maximum)	110 G [†]	160 G [‡]
Altitude (maximum)	-15.2 m to 3048 m (-50 ft to 10,000 ft)	-15.2 m to 10,668 m (-50 ft to 35,000 ft)

* Measured using a random vibration spectrum that simulates user environment.

† Measured using a 2 ms half-sine pulse when the hard drive is in use.

‡ Measured using a 2 ms half-sine pulse when the hard-drive head is in parked position.

Keyboard shortcuts

Keys	Description
	Mute audio
	Decrease volume
	Increase volume
	Play previous track/chapter
	Play/Pause
	Play next track/chapter
	Switch to external display
	Search
	Toggle keyboard backlight
	Decrease brightness
	Increase brightness
 + 	Turn off/on wireless
 + 	Pause/Break
 + 	Sleep
 + 	Toggle scroll lock
 + 	Toggle between power and battery-status light/hard-drive activity light

Keys	Description
 Fn + R	System request
 Fn + Ctrl	Open application menu
 Fn + Esc	Toggle Fn-key lock
 Fn + End →	End
 Fn + ←Home	Home
 Fn + ↓PgDn	Page down
 Fn + ↑PgUp	Page up

Getting help and contacting Dell

Self-help resources

You can get information and help on Dell products and services using these self-help resources:

Information about Dell products and services www.dell.com

Dell Help & Support app



Get started app



Accessing help

In Windows search, type **Help and Support**, and press Enter.

Online help for operating system

www.dell.com/support/windows
www.dell.com/support/linux

Troubleshooting information, user manuals, setup instructions, product specifications, technical help blogs, drivers, software updates, and so on.

www.dell.com/support

Learn about your operating system, setting up and using your computer, data backup, diagnostics, and so on.

See *Me and My Dell* at www.dell.com/support/manuals.

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.

 **NOTE:** Availability varies by country and product, and some services may not be available in your country.



NOTE: If you do not have an active internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.