



## Philips Water container

- For SENSEO Switch coffee maker
- Transparent

CP0404

## For water storage in your SENSEO coffee machine

Go to the Specs Tab to check your matching product

A water container should be cleaned regularly. Whenever that's the case, you'll be happy not to miss your coffee moment and to have an extra reservoir for your SENSEO® Switch coffee maker. The tank contains 1 liter.

### **Ease of using Philips spare parts**

- Easy renew your product with original Philips parts

# PHILIPS

Water container  
For SENSEO Switch coffee maker Transparent

# Specifications

## Suitable for:

- SENSEO® Switch: HD7892

CP0404/01

# Highlights

## Easy renew of product parts

From time to time your product needs a facelift but it was never so easy like with Philips consumer replacement parts to renew your product. This all with guaranteed Philips quality.



Issue date 2016-12-16

Version: 1.0.1

© 2016 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)