Inspiron 15 3000 Setup and Specifications



Notes, cautions, and warnings



NOTE: A NOTE indicates important information that helps you make better use of your product.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

Copyright © 2016 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2016 - 11

Rev. A00

Contents

S	et up your computer	5
V	iews	Ω
V	Front	
	Left	
	Right	
	Base	
	Display	
	Back	
	200	
S	pecifications	13
	Dimensions and weight	
	System information	
	Memory	13
	Ports and connectors	14
	Communications	14
	Audio	15
	Storage	15
	Media-card reader	15
	Keyboard	16
	Camera	16
	Touch pad	16
	Power adapter	17
	Battery	17
	Display	18
	Video	18
	Computer environment	18



Keyboard shortcuts	
Getting help and contacting Dell	22
Self-help resources	22
Contacting Dell	22



Set up your computer

1 Connect the power adapter and press the power button.



Figure 1. Connect the power adapter and pressing the power button



2 Finish operating system setup.

For Windows:

a) Connect to a network.



Figure 2. Connecting to a wireless network

b) Sign-in to your Microsoft account or create a new account.




Figure 3. Signing in to your Microsoft account or create a new account

For Ubuntu:

Follow the instructions on the screen to finish setup.



3 Locate Dell apps in Windows.

Table 1. Locate Dell apps



Register your computer

Dell Help & Support





Figure 4. Dell Help & Support




 ${\bf SupportAssist-- Check\ and\ update\ your\ computer}$



Views

Front



Power and battery-status light/hard-drive activity light

Indicates the battery-charge status or the hard-drive activity.



NOTE: Press Fn+H to toggle this light between power and batterystatus light and hard-drive activity light.

Hard-drive activity light

Turns on when the computer reads from or writes to the hard drive.

Power and battery-status light

Indicates the power and battery-charge status.

Solid white — Power adapter is connected and the battery has more than 5% charge.

Amber — Computer is running on battery and the battery has less than 5% charge.

Off

- Power adapter is connected and the battery is fully charged.
- Computer is running on battery and the battery has more than 5% charge.
- Computer is in sleep state, hibernation, or turned off.

Left





1 Power-adapter port

Connect a power adapter to provide power to your computer and charge the battery.

2 Network port

Connect an Ethernet (RJ45) cable from a router or a broadband modem for network or internet access.


3 HDMI port

Connect a TV or another HDMI-in enabled device. Provides video and audio output.

4 USB 3.0 ports (2)

Connect peripherals such as storage devices and printers. Provides data transfer speeds up to 5 Gbps.

Right



1 SD-card slot

Reads from and writes to the SD card.

2 Headset port

Connect a headphone or a headset (headphone and microphone combo).

3 **USB 2.0 port**

Connect peripherals such as storage devices and printers. Provides data transfer speeds up to 480 Mbps.

4 Optical drive (optional)

Reads from and writes to CDs and DVDs.

5 Security-cable slot

Connect a security cable to prevent unauthorized movement of your computer.



Base



Left-click area

Press to left-click.

2 Touch pad

Move your finger on the touch pad to move the mouse pointer. Tap to left-click and two finger tap to right-click.

3 Right-click area

Press to right-click.

Power button 4

Press to turn on the computer if it is turned off, in sleep state, or in hibernate state.

Press to put the computer in sleep state if it is turned on.


Press and hold for 4 seconds to force shut-down the computer.



NOTE: You can customize the power-button behavior in Power Options. For more information, see Me and My Dell at www.dell.com/ support/manuals.



Display



1 Camera

Enables you to video chat, capture photos, and record videos.

2 Camera-status light


Turns on when the camera is in use.

3 Microphone

Provides digital sound input for audio recording, voice calls, and so on.



Back



1 Battery

Supplies power to the computer. It enables the computer to work without connecting to an electrical outlet for a limited time.

2 Regulatory label (in battery bay)

Contains regulatory information of your computer.

3 Service Tag label

The Service Tag is a unique alphanumeric identifier that enables Dell service technicians to identify the hardware components in your computer and access warranty information.

4 Battery-release latch

Lock/unlock the battery in the battery bay. Slide the latch to the unlock position, to release the battery.



Specifications

Dimensions and weight

Table 2. Dimensions and weight

Height 23.65 mm (0.93 in)

Width 380 mm (14.96 in)

Depth 260.30 mm (10.25 in)

Weight (approximate) 2.30 kg (5.07 lb)



NOTE: The weight of your computer varies depending on the configuration ordered and the manufacturing variability.

System information

Table 3. System information

Computer model Inspiron 15-3567

Processor · 7th generation Intel Core i3/i5/i7

6th generation Intel Core i3

Chipset Integrated in the processor

Memory

Table 4. Memory specifications

Slots Two SODIMM slots

Type DDR4

Speed 2133 MHz

Configurations supported 4 GB, 6 GB, and 8 GB



Ports and connectors

Table 5. Ports and connectors

External:	
Network	One RJ-45 port
USB	One USB 2.0 portTwo USB 3.0 ports
Audio/Video	One HDMI portOne headset (headphone and microphone combo) port

Table 6. Internal Ports and connectors

Internal:	
M2 card	One M.2 slot for Wi-Fi/Bluetooth

Communications

Table 7. Communication specifications

Ethernet	10/100 Mbps Ethernet controller integrated on system board
Wireless	 WiFi 802.11ac+Bluetooth 4.2 WiFi 802.11ac+Bluetooth 4.1 Wi-Fi 802.11b/g/n+Bluetooth 4.0 Miracast



NOTE: Windows 10 supports up to Bluetooth 4.1.



Audio

Table 8. Audio specifications

Controller ALC 3246 with Waves MaxxAudio

Speakers Two

Speaker output • Average: 2 W

· Peak: 2.5 W

Microphone Single digital microphone in the camera

assembly

Volume controls Media-control shortcut keys

Storage

Table 9. Storage specifications

Interface . SATA 6 Gbps for hard drive

SATA 1.5 Gbps for optical drive

Hard drive One 2.5-inch drive

Optical-drive (optional) One 9.5 mm DVD+/-RW drive

Media-card reader

Table 10. Media-card reader specifications

Type One SD-card slot

Cards supported • Secure Digital (SD)

Secure Digital High Capacity (SDHC)

Secure Digital Extended Capacity

(SDXC)



Keyboard

Table 11. Keyboard specifications

Type Standard keyboard

Shortcut keys Some keys on your keyboard have two

symbols on them. These keys can be used to type alternate characters or to perform secondary functions. To type the alternate character, press Shift and the desired key. To perform secondary functions, press Fn and the desired key.

Ø

NOTE: You can define the primary behavior of the function keys (F1– F12) by changing Function Key Behavior in BIOS setup program.

Keyboard shortcuts

Camera

Table 12. Camera specifications

Resolution . Still image: 0.9 megapixel

Video: 1280x720 (HD) at 30 fps

Diagonal viewing angle 74.9 degrees

Touch pad

Table 13. Touch pad

Resolution . Horizontal: 2040

Vertical: 1240

Dimensions • Width: 105 mm (4.13 in)

Height: 65 mm (2.56 in)

D&LL

Power adapter

Table 14. Power adapter specifications

	45 W	65 W
Input current (maximum)	1.30 A	1.70 A
Output current (continuous)	2.31 A	3.34 A
Input voltage	100 VAC-240 VAC	
Input frequency	50 Hz-60 Hz	
Rated output voltage	19.50 VDC	
Temperature range	 Operating: 0°C to 40°C (32°F to 104° Storage: -40°C to 70°C (-40°F to 15°) 	,

Battery

Table 15. Battery specifications

Туре	4-cell "smart" lithium-ion (40 Whr)
Dimensions	Width: 270 mm (10.63)Depth: 37.5 mm (1.47 in)Height: 20 mm (0.79 in)
Weight (maximum)	0.25 kg (0.55 lb)
Voltage	14.8 VDC
Operating time	Varies depending on operating conditions and can significantly reduce under certain power-intensive conditions.
Life span (approximate)	300 discharge/charge cycles
Temperature range	• Operating: 0°C to 35°C (32°F to 95°F)



• Storage: -40°C to 65°C (-40°F to 149°F)

Coin-cell battery CR-2032

Display

Table 16. Display specifications

Туре	15-inch HD non-touch screen	15-inch HD touch screen
Resolution (maximum)	1366 x 768	1366 x 768
Viewing angle (Left/ Right/Up/Down)	40/40/10/30 degrees	40/40/10/30 degrees
Pixel pitch	0.252 mm	0.252 mm
Dimension:		
Height (excluding bezel)	193.5 mm (7.62 in)	193.5 mm (7.62 in)
Width (excluding bezel)	344.2 mm (13.55 in)	344.2 mm (13.55 in)
Diagonal (excluding bezel)	394.86 mm (15.55 in)	394.86 mm (15.55 in)

Video

Table 17. Video specifications

	Integrated	Discrete
Controller	Intel HD Graphics 520Intel HD Graphics 620	AMD R5 M430
Memory	Shared system memory	Up to 2 GB DDR3

Computer environment

Airborne contaminant level: G1 as defined by ISA-S71.04-1985



Table 18. Computer environment

	Operating	Storage
Temperature range	0°C to 35°C (32°F to 95°F)	-40°C to 65°C (-40°F to 149°F)
Relative humidity (maximum)	10% to 90% (non-condensing)	0% to 95% (non- condensing)
Vibration (maximum)*	0.66 GRMS	1.30 GRMS
Shock (maximum)	110 G [†]	160 G [‡]
Altitude (maximum)	-15.2 m to 3048 m (-50 ft to 10,000 ft)	-15.2 m to 10,668 m (-50 ft to 35,000 ft)

^{*} Measured using a random vibration spectrum that simulates user environment.



 $[\]dagger$ Measured using a 2 ms half-sine pulse when the hard drive is in use.

[‡] Measured using a 2 ms half-sine pulse when the hard-drive head is in parked position.

Keyboard shortcuts

Table 19. List of keyboard shortcuts

Keys	Description
F1	Mute audio
F2 🐠	Decrease volume
F3 (0)	Increase volume
F4	Play previous track/chapter
F5 ▶II	Play/Pause
F6 ▶₩	Play next track/chapter
F8 🚉	Switch to external display
F9 p	Search
F11 ★	Decrease brightness
F12	Increase brightness
Fn + PrtScr	Turn off/on wireless
Fn + Insert	Sleep
Fn + H	Toggle between power and battery- status light/hard-drive activity light
Fn + Esc	Toggle Fn-key lock
Fn + TPgUp	Page up



Keys	Description
Fn + \plus PgDn	Page down
Fn + ←Home	Home
Fn + End →	End



Getting help and contacting Dell

Self-help resources

You can get information and help on Dell products and services using these self-help resources:

Table 20. Self-help resources

Information about Dell products and

services

Dell Help & Support app

www.dell.com



Get started app



Accessing help In Windows search, type Help and

Support, and press Enter.

Online help for operating system <u>www.dell.com/support/windows</u>

www.dell.com/support/linux

www.dell.com/support

Troubleshooting information, user manuals, setup instructions, product specifications, technical help blogs, drivers, software updates, and so on.

Learn about your operating system, See *Me and My D* setting up and using your computer, data support/manuals. backup, diagnostics, and so on.

See Me and My Dell at www.dell.com/

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.



