


# PHILIPS

## Brush Head Replacement

Summer brush head  
with soft sponge

MS598/51



## Refreshed and ready for the summer with soft sponge and bristles

The brush head consists of an outer ring of power bristles that effectively draw out oil and dirt from the pores and a soft sponge in the center, that removes the sweat and dirt

### **Fits into your daily routine**

- Replace the brush head every 3 months for a hygienic use

### **Cleanse more than 90% summer stickiness**

- Create bubbles and take away summer stickiness

### **Compatibility**

- Compatible with Philips VisaPure Men range


### **Developed for all skin types**

- Unique design for comfortable, yet thorough cleansing

# Highlights

**Compatibility (Visapure Men)**

Compatible with Philips VisaPure Men range

**Replace heads every 3 months**

To keep your VisaPure MEN hygienic, replace your brush head every 3 months by simply clicking on a new brush head replacement onto your VisaPure MEN.

**Summer brush**

Summer brush consists of 2 special parts that removes excessive oil, dirt and sweat from your face. The 8,000 round-edge bristles bread up the deeply-seated oil on your skin. Then the sponge in middle will create bubble

and strenthen the absorption of the excessive oil, makes your feel refreshed after the cleansing

**Developed for all skin types**

The 8,000 thin rounded tip bristles and soft sponge create a comfortable cleansing experience for all skin types. Especially suitable for summer usage.

# Specifications

**Cleaning**

**Wash with water and mild soap:** Dry brush with a towel

**Maintenance**

Replace head every 3 months

