


HD CAR CAMERA
Salora CDC25

OWNER'S MANUAL

INSTRUCTIONS



1.	Up	6.	Lock	11.	Display
2.	Menu	7.	Reset/MIC	12.	Lens
3.	Down	8.	Power On/Off	13.	Mounting socket
4.	OK	9.	TF card	14.	USB
5.	Mode	10.	Speaker	15.	LED light

Power supply:

1. Built-in camera
2. USB power

Features:

Insert the Micro SD card before using the camera; all files will be saved on the SD card.

1. On/Off function:
Power on: press briefly the Power On/Off button (8) to activate the camera.
2. Recording function:
Video mode: in Recording standby mode: press briefly the OK button (4) to start the recording, press again to stop recording and the video file will be saved.
3. Camera function:
Photo mode: in Photo standby mode: press briefly the OK button (4) to take a picture.
4. Playback function:
Playback: in Playback standby mode: press the Up or Down button (1/3) to select a file you would like to see, then press the OK button (4) to start the playback.
5. Lock function:
By pressing the Lock button (6), the current video will be locked.

Video mode:

By pressing the Menu button (2) you can select the Video mode and enter the menu settings.

1. Video Size :
720P; VGA; select the desired resolution and press the OK button (4) to confirm.
2. Date/Time stamp
Off, On, Date, Date&Time
3. Motion Detection: Off/On:
Off: The camera will be in standby and will not record.
On: The camera will be in standby, as soon as a movement in front of the camera will be detected, the camera will start recording.
4. Loop Time:
Off/1min/3min/5min/10min.
5. Voice command:
On/Off: When activated, you can start the registration by voice command.

Photo Menu:

By pressing the Menu button (2) you can select the Photo mode and enter the menu settings.

1. Resolution:
3M/2M/1M/VGA

System Menu:

Press the Menu button (2) than press the Menu button (2) again to enter the System Settings Menu.

1. Format: Cancel/OK
2. Language: English, Chinese, Japanese, French, German, Korean, Italian, Portuguese and more.
3. Auto off: 1min/3min/5min/off, the camera will go into standby mode automatically after the preset time.
4. System reset: Cancel/OK
5. Light Frequency: 50Hz/60Hz
6. DATE: select year/month/day
7. USB: PC CAM/Disk drive

Download file:

Select the USB disk drive, connect the USB cable to your computer, the computer will read the disk, select the file you wish to read, copy or delete.

Technical parameters

LCD screen size	2.4 inch High Definition display
Video Max resolution	HD; VGA
Video format	AVI
Image Max resolution	3M, 2M, 1M
Micro SD Card	Support 4GB-32Gb
Night vision function	Support
Microphone/Speaker	Internal
Power Interface	5VDC/500mah
Battery	Built-in

Note: We reserve the right to modify the design and specifications without prior notice.