

Philips VisaCare Replacement tip Brightening

Brighter looking skin

All skin types For daily use Replace every 2 months



SC6895/03





Brightening tip for brighter looking skin

use only with Philips VisaCare

When your skin is young it renews fast and is firm and glowing. With time your skin's metabolism slows down. That's why we have introduced VisaCare Prestige: your skin rejuvenation solution to address loss of firmness and dull complexion.

Brightening tip for smooth brighter looking skin

• Remove dull skin cells for smooth, brighter looking skin

Gentle on your skin

- 150.000 crystal particles gently remove dull skin cells
- Suitable for all skin types

Easy to use


- · Brightening tip can be used every day for optimal results
- Easy click on replacement tip
- For the best results, replace every two months





Highlights

Brighter looking skin



Gentle pinching removes old, dull skin cells for smooth, brighter looking skin. 150.000 crystal particles embedded in the tip work gently but effectively on the skin. 86% of the women agree*: "my skin looks more youthful". And 86% of women agree*: "my skin looks brighter***"

Gently renew your skin



The crystal particles on the tip are gentle on your skin, as they are up to 20 times smaller than your normal scrub particles.

Brightening tip for daily use



Achieve immediate, optimal results with just 5 minutes treatment every day using the brightening tip.

Suitable for all skin types



Can be used on all skin types, even delicate skin.

Easy to replace



Easy click on technique, fits on all VisaCare devices.

Replace every 2 months

For best results, we recommend replacing every two



Version: 1.1.1

© 2017 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.





Specifications

Ease of use

- Recommended replacement: Every 2 months
- Compatible with: Philips SC6220, Philips SC6240, Philips SC6250
- Cleaning: Wash under fresh water
- Replacement: Easy click-on tip

